BOP 210/211 1.2

Oven

Table of contents

Intended use	3
Important safety information	4
Causes of damage	6
Environmental protection	6
Saving energy	6
Environmentally-friendly disposal	6
Familiarising yourself with your appliance	7
Oven	7
Display and operating controls	8
Symbols	8
Colours and display	8
Standby	9
Activating the appliance	9
Additional information 1 and 1 [®]	9 9
Cooling fan Function selector positions	9 10
Accessories	10
Special accessories	11
Before using the appliance for the first time	12
Setting the language	12
Setting the time format	12
Setting the clock	12
Setting the date format	12
Setting the date	12
Setting the temperature unit	12
Ending initial set-up	12
Heating up the oven	12
Cleaning accessories	12
Operating the appliance	13
Cooking compartment	13
Inserting accessories	13
Switching on	13
Rapid heating	13
Safety shut-off	13

Timer functions	14
Calling up the timer menu	14
Timer	14
Stopwatch	14
Cooking time	15
End of cooking time	16
Long-term timer	17

Long-term timer	17
Setting the long-term timer	17

Individual recipes17Recording a recipe17Programming a recipe18Entering names18

Starting recipes	18
Change recipe	19
Deleting recipes	19
Childproof look	10
Childproof lock	19
Activate the child lock	19
Deactivating the child lock	19
Home Connect	20
Setting up	20
Remote Start	21
Home Connect settings	21
Remote diagnostics	22
About data protection	22
Declaration of Conformity	22
Basic settings	23
Cleaning and maintenance	25
Cleaning agents	25
Removing the rails	26
Catalytic cleaning (cleaning aid)	26
Preparing catalytic cleaning	26
Starting catalytic cleaning	26
What to do in the event of a fault	27
Power cut	27
Demo mode	27
Replacing the oven light bulb	28
After-sales service	28
E number and FD number	28
Tables and tips	29
Vegetables	30
Side dishes and meals	31
Fish	33
Meat	33
	34
Poultry Crilling and reacting	37
Grilling and roasting	
Baked items	39
Desserts Preserving	44
Preserving Disinformation	44
Disinfecting	45
Drying Delving store	45
Baking stone	46
Acrylamide in foodstuffs	47

Additional information on products, accessories, replacement parts and services can be found at www.gaggenau.com and in the online shop www.gaggenau.com/zz/store

Intended use

Read these instructions carefully. Only then will you be able to operate your appliance safely and correctly. Retain the instruction manual and installation instructions for future use or for subsequent owners.

This appliance is only intended to be fully fitted in a kitchen. Observe the special installation instructions.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance is intended for domestic use only. The appliance must only be used for the preparation of food and drink. The appliance must be supervised during operation. Only use this appliance indoors.

This appliance is intended for use up to a maximum height of 2000 metres above sea level.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 15 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

Always slide accessories into the cooking compartment correctly. See description of accessories in the instruction manual.

${ m Important}$ safety information

▲ Warning – Risk of fire!

- Combustible items stored in the cooking compartment may catch fire. Never store combustible items in the cooking compartment. Never open the appliance door if there is smoke inside. Switch off the appliance and unplug it from the mains or switch off the circuit breaker in the fuse box.
- A draught is created when the appliance door is opened. Greaseproof paper may come into contact with the heating element and catch fire. Do not place greaseproof paper loosely over accessories during preheating. Always weight down the greaseproof paper with a dish or a baking tin. Only cover the surface required with greaseproof paper. Greaseproof paper must not protrude over the accessories.

▲ Warning – Risk of burns!

- The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.
- The inside of the appliance door becomes very hot during operation. Always open the appliance door as far as it will go. Ensure that the appliance door does not swing back. Avoid contact with the inside of the appliance door.
- Accessories and ovenware become very hot. Always use oven gloves to remove accessories or ovenware from the cooking compartment.
- Alcoholic vapours may catch fire in the hot cooking compartment. Never prepare food containing large quantities of drinks with a high alcohol content. Only use small quantities of drinks with a high alcohol content. Open the appliance door with care.

- Bulbs become very hot when switched on. There is still a risk of burning for some time after they have been switched off. Allow the bulbs to cool down before cleaning the appliance. Switch off appliance light during cleaning.
- Bulbs become very hot when switched on. There is still a risk of burning for some time after they have been switched off. Allow the bulbs to cool down before replacing them.

▲ Warning – Risk of scalding!

- The accessible parts become hot during operation. Never touch the hot parts. Keep children at a safe distance.
- When you open the appliance door, hot steam may escape. Open the appliance door with care. Keep children at a safe distance.
- Water in a hot cooking compartment may create hot steam. Never pour water into the cooking compartment when the cooking compartment is hot.

▲ Warning – Risk of injury!

Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.

▲ Warning – Risk of electric shock!

- Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.
- The cable insulation on electrical appliances may melt when touching hot parts of the appliance. Never bring electrical appliance cables into contact with hot parts of the appliance.

- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- When replacing the cooking compartment bulb, the bulb socket contacts are live.
 Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

▲ Warning – Risk of burns!

The appliance will become very hot on the outside during the cleaning function. Never touch the appliance door. Allow the appliance to cool down. Keep children at a safe distance.

Causes of damage

Caution!

- Accessories, foil, greaseproof paper or ovenware on the cooking compartment floor: Do not place accessories on the cooking compartment floor. Do not cover the cooking compartment floor with any sort of foil or greaseproof paper. Do not place ovenware on the cooking compartment floor. This will cause heat to accumulate. The baking and roasting times will no longer be correct and the enamel will be damaged.
- Water in a hot cooking compartment: do not pour water into the cooking compartment when it is hot. This will cause steam. The temperature change can cause damage to the enamel.
- Moist food: do not store moist food in the cooking compartment when it is closed for prolonged periods This will damage the enamel.
- Fruit juice: when baking particularly juicy fruit pies, do not pack the baking tray too generously. Fruit juice dripping from the baking tray leaves stains that cannot be removed. If possible, use the deeper universal pan.
- Cooling with the appliance door open: only allow the cooking compartment to cool when it is closed. Even if the appliance door is only open a little, front panels of adjacent units could be damaged over time.
- Very dirty door seal: If the door seal is very dirty, the appliance door will no longer close properly when the appliance is in use. The fronts of adjacent units could be damaged. Always keep the door seal clean.
- Appliance door as a seat, shelf or worktop: Do not sit on the appliance door, or place or hang anything on it. Do not place any cookware or accessories on the appliance door.
- Inserting accessories: depending on the appliance model, accessories can scratch the door panel when closing the appliance door. Always insert the accessories into the cooking compartment as far as they will go.
- Carrying the appliance: do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.

Environmental protection

The sections below list a number of energy-saving tips and provide information on disposing of your appliance.

Saving energy

- Use dark-coloured, black-coated or enamelled baking tins. These absorb the heat particularly well.
- Open the appliance door as little as possible during operation.
- If you are baking more than one cake, it is best to bake them one after the other. The fact that the oven is still warm will reduce the baking time for the second cake. You can also place two loaf tins next to each other.
- In hot air mode, you can bake on more than one level at a time.
- If the cooking time is relatively long, you can switch the appliance off 10 minutes before the cooking time ends and use the residual heat to finish cooking.

Environmentally-friendly disposal

Dispose of packaging in an environmentally-friendly manner.




This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

Familiarising yourself with your appliance

Use this section to familiarise yourself with your new appliance. The control panel and the individual operating controls are explained. You will find information on the cooking compartment and the accessories.

Oven




З

1	Door seal
2	Grill heating element
3	Socket for additional heating element (special accessory for baking stone)

Display and operating controls

These instructions are valid for different versions of the appliance. There may be minor differences depending on the appliance model.

All versions of the appliance are operated in an identical manner.



Symbols

Symbol	Function
•	Start
	Stop
II	Pause/End
Χ	Cancel
С	Delete
\checkmark	Confirm/save settings
>	Selection arrow
i	Call up additional information
>>>	Rapid heating with status indicator
	Call up individual recipes
rec	Record menu

<u> </u>	Edit settings
≻ <u>A</u> [¤]	Enter name
X	Delete letters
<u>-</u>	Child lock
0	Call up timer menu
	Call up long-term timer
*	Demo mode
(((-	Network connection (Home Connect)

Colours and display

Colours

The different colours are used to guide the user in the relevant setting situations.

Orange	Initial settings
	Main functions
Blue	Basic settings
	Cleaning
White	Values which can be set

Appearance

Depending on the situation, the appearance of symbols, values or the entire display changes.

Zoom	The setting that you are changing will appear larger on the display.
	If you have set a time and it is about to run out, it will appear larger on the display just before it runs out (e.g. 60 seconds before the end, if you have set the timer).
Pared-down display	After a short while, the amount of information shown on the display will be reduced and only the most important information will remain.This function is pre-set and can be changed in the basic settings.



Standby

The appliance switches to standby mode if no function is set or the childproof lock is activated.

The brightness of the control panel is dimmed in standby mode.

Notes

- Different things can be displayed in standby mode. The default setting is the GAGGENAU logo and the time.
- The brightness of the display depends on the vertical viewing angle.
- You can change the display and the brightness at any time in the basic settings. → "Basic settings" on page 23

Activating the appliance

To exit standby mode, you can either

- Turn the function selector,
- Touch a control panel,
- Open or close the door.

You can now set the desired function. You can read about how to set functions in the respective chapters.

Notes

- When "Standby screen = off" is selected in the basic settings, you must turn the function selector to exit standby mode.
- The appliance returns to the standby screen if you have not made any settings for a long time after activation.
- When the door is open, the interior lighting switches off after a short time.

Additional information ${f i}$ and ${f i}^{\scriptscriptstyle (0)}$

By touching the i symbol, you can call up additional information. For example, information on the type of heating set or on the current temperature of the cooking compartment.

Note: During continuous operation after heating up, slight deviations in temperature are normal.

The i^{\odot} symbol appears for important information and indicates that an action is required. Important information on safety and operating status is also occasionally displayed automatically. These messages disappear automatically after a few seconds or must be confirmed with \checkmark .

With Home Connect messages, the Home Connect status additionally appears in the i^{\odot} . You will find more information about this in the section entitled \rightarrow "Home Connect" on page 20.

Cooling fan


Your appliance has a cooling fan. The cooling fan switches on during operation. Depending on the appliance version, the hot air escapes above or under the door.

After removing cooked food, keep the door closed until the appliance cools down. The appliance door must not be left ajar, as adjoining kitchen furniture may be damaged. The cooling fan continues to run for a certain time after operation and then switches off automatically.

Caution!

Do not cover the ventilation slots. Otherwise, the appliance will overheat.

Function selector positions



Position	Function/type of heating	Temperature	Application	
0	"Off" position			
्रेट	Light			
2	4	50–300 °C	Hot air: For cakes, biscuits and bakes on more than	
	Hot air Default temperature 170 °C ^{one level.}	one level.		
			The fan in the back wall of the oven distributes the heat evenly throughout the cooking compartment.	
3	S [°]	50–300 °C	Energy-saving hot air mode for cakes, meat, bakes	
	Eco hot air*	Default temperature 170 °C	and gratins. Residual heat is optimally used. Conveni- ence functions remain switched off (e.g. the interior lighting). The interior temperature can only be dis- played while the appliance is heating up. Do not pre- heat the oven.	
			Make sure that the cooking compartment is cold and that there is nothing already in there when you place the food inside. Then start the specified cooking time. Always keep the appliance door closed when cook- ing. This will prevent heat loss.	
4		50–300 °C	For cakes in tins or on a baking tray, bakes, roasts.	
	Top + bottom heating	Default temperature 170 °C		
5		50–300 °C	Targeted heat from above, for example grilling fruit	
	Top heating	Default temperature 170 °C	flan with meringue.	
6		50-300 °C	For adding extra baking time (such as for moist fruit	
	Bottom heating	Default temperature 170 °C	flans), for boiling down, for dishes in a bain marie.	
7	<u>\$</u>	50–300 °C	Additional heat from below for moist cakes, such as	
	Hot air + bottom heating	Default temperature 170 °C	fruit flan.	
8	le contraction de la contracti	50-300 °C	Even, all-round heating for meat, poultry and whole	
	Full surface grill + air recircu- lation	Default temperature 220 °C	fish.	
9		50–300 °C	For grilling flat pieces of meat, sausages or fillets of	
	Full surface grill	Default temperature 220 °C	fish. Grilling and browning.	
10		50–300 °C	Can only be used with the baking stone and heating	
	Baking stone function	Default temperature 250 °C	element – these are optional accessories. Baking stone heated from below for crisp stone-baked	
	<i>(</i>)		pizza, bread or bread rolls.	
S	/ Basic settings		Your appliance can be adjusted to your requirements	
		200 °C	in the basic settings.	
	Catalytic cleaning	300 °C	Cleaning aid	
* Turco	of heating used to determine th	a anaray officianay alaga in ana	ordance with EN 60250 1	

Accessories

Use only the accessories supplied with the product or available from the after-sales service. They are specially

designed for your appliance. Ensure that you always insert the accessories into the cooking compartment the right way round. Your appliance is equipped with the following accessories:



Baking tray, enamelled

Wire rack





Enamelled grill tray

Special accessories

You can order the following special accessories from your specialist dealer:

BA 036 102	Wire rack, chromium-plated, without opening, with feet
BA 046 115	Glass dish, 24 mm deep
BA 056 115	Heating element for baking stone (230 V)
BA 056 130	Baking stone
	Including baking stone support and pizza paddle (order heating element separately)
BA 216 102	Telescopic extension rail
BA 226 102	Grill tray, enamelled, 37 mm deep
BA 226 112	Baking tray, enamelled, 24 mm deep
BS 020 002	Pizza paddle, set of 2
00664048	Oven ceiling with special catalytic enamelling, for retrofitting
00664248	Oven back wall with special catalytic enamelling, for retrofitting
Only use the	accessories as specified. The

Only use the accessories as specified. The manufacturer accepts no liability if these accessories are used incorrectly.

Remove any accessories that are not required during operation from the cooking compartment. Bush for the additional heating element at the back of the cooking compartment: Always leave the cover in during normal operation without the additional heating element.

Before using the appliance for the first time

In this section, you can find out what you must do before using your appliance to prepare food for the first time. First read the section entitled \rightarrow "Important safety information" on page 4.

The appliance must be fully installed and connected to the mains.

After connecting the appliance to the power supply, the "Initial settings "menu will be displayed. Now you can now configure your new appliance for initial set-up.

Notes

The "Initial settings" menu will appear only after the appliance has been connected to a power supply and switched on for the first time, or if the appliance has not been connected to a power supply for a number of days.
 Once the appliance has been connected to a power supply the CACCENALL lags will appear first for

supply, the GAGGENAU logo will appear first for approximately 30 seconds. The "Initial settings" menu will then appear automatically.

You can change the settings at any time in the basic settings. → "Basic settings" on page 23

Setting the language

The preset language appears in the display.

- 1 Turn the rotary selector to select the required display language.
- Confirm with ✓.

Setting the time format

The two possible formats 24h and AM/PM appear in the display. The default is the 24h format.

- 1 Use the rotary selector to select the desired format.
- 2 Confirm with √.

Setting the clock

The time is shown in the display.

- 1 Set the desired time using the rotary selector.
- 2 Confirm with ✓.

Setting the date format

The three possible formats D.M.Y, D/M/Y and M/D/Y appear in the display. The default is the D.M.Y format.

- 1 Use the rotary selector to select the desired format.
- **2** Confirm with \checkmark .

Setting the date

The preset date appears in the display. The day setting is already active.

- 1 Set the day using the rotary selector.
- 2 Touch the > symbol to switch to the month setting.
- 3 Set the month using the rotary selector.
- 4 Touch the > symbol to switch to the year setting.
- 5 Set the year using the rotary selector.
- 6 Confirm with \checkmark .

Setting the temperature unit

The two possible units $^{\circ}C$ and $^{\circ}F$ will appear on the display. The default unit is $^{\circ}C$.

- 1 Use the rotary selector to select the unit you require.
- **2** Confirm with \checkmark .

Ending initial set-up

"Initial set-up complete" will appear on the display.

Confirm with \checkmark .

The appliance will switch to standby mode and the standby display will appear. The appliance is now ready to use.

Heating up the oven

Make sure that there is no leftover packaging in the cooking compartment.

To eliminate the new-appliance smell, heat up the oven with it empty and the door closed. One hour with hot air $rac{1}{2}$ at 200 °C is ideal for this.

Cleaning accessories

Before using the accessories for the first time, clean them thoroughly using hot detergent solution and a soft cloth.


Operating the appliance

Cooking compartment

▲ Warning – Risk of scalding!!

The inside of the appliance door becomes very hot during operation. Always open the appliance door as far as it will go. Ensure that the appliance door does not swing back. Avoid contact with the inside of the appliance door.

The cooking compartment has four shelf positions. The shelf positions are counted from the bottom up.



Caution!


- Do not place anything on the cooking compartment floor. Do not cover it with aluminium foil. A build-up of heat could damage the appliance.
- Do not slide any accessories between the shelf positions, or they may tip.

Inserting accessories

The accessories have a locking function. The locking function prevents the accessories from tilting when they are pulled out. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.

When inserting the wire rack, make sure that

- the lug A is pointing downwards
- the safety bar **B** on the wire rack is at the back and on top.



Switching on

- 1 Set the required heating mode using the function selector. The chosen heating mode and the default temperature are displayed.
- 2 If you want to change the default temperature: set the required temperature with the rotary selector.

The preheating symbol \geq appears on the display. The bar continuously shows the preheating status. When the set temperature is reached, a signal sounds and the preheating symbol \geq goes off.

Note: The oven interior lighting stays switched off at a temperature setting below $70^{\circ}C$

Switching off:

Turn the function selector to **0**.

Rapid heating

With the "Rapid heating" function, your appliance reaches the temperature you require particularly quickly in the "top heat", "bottom heat" and "top+ bottom heat" types of heating.

To ensure an even cooking result, do not place your food in the cooking compartment until "Rapid heating" is complete and the heat-up symbol \ge has gone out.

Note: The "Rapid heating" function is preconfigured in the factory settings. You can select "Rapid heating" $\xrightarrow{>}$ or "Heat-up" $\widehat{}$ in the basic settings. \rightarrow "Basic settings" on page 23

Safety shut-off

For your protection, the appliance is equipped with an automatic safety shut-off. Any heating process is switched off after 12 hours if the oven is not operated in this time. A message appears in the display.

Exception:

The long-term timer has been programmed.

Set the function selector to **0**, then the appliance can be operated again as usual.

Timer functions

You use the timer menu to make the following settings:

- Short-term timer
- Stopwatch
- Cooking time (not in standby mode)
- () Cooking time end (not in standby mode)

Calling up the timer menu

You can call up the timer menu from any mode. Only from the basic settings, function selector is set to **S**, the timer menu is not available.

Touch the 🕓 symbol.



The timer menu is displayed.

Timer

The timer runs independently of the other appliance functions. You can enter a maximum of 90 minutes.


Setting the timer

- Call up timer menu. The "Timer" ∑ function is displayed.
- 2 Turn the rotary selector to set the required cooking time.



3 Start with ▶.

The timer menu closes and the time begins to count down. The Σ symbol and the countdown appear in the display.



A signal sounds once the time has elapsed. Touch the \checkmark symbol to silence.

You can exit the timer menu at any time by pressing the X symbol. This erases the settings.

To stop the timer:

Call up timer menu. Touch > to select the "Timer" Ξ function and touch the **II** symbol. To allow the timer to continue counting down, touch the symbol >.

Switching off the timer early:

Call up timer menu. Touch > to select the "Timer" Ξ function and touch the \mathbb{C} symbol.

Stopwatch


The stopwatch runs independently of the other appliance functions.

The stopwatch counts from 0 seconds up to 90 minutes.

It also has a pause function, which enables you to temporarily stop the clock.


Starting the stopwatch

- 1 Call up the timer menu.
- 2 Touch > to select the $\overline{\odot}$ "Stopwatch" function.




3 Touch ▶ to start.

The timer menu is closed and the timing begins. The $\bar{\odot}$ symbol and the elapsed time are shown in the display.



Pausing and restarting the stopwatch

- 1 Call up the timer menu.
- 2 Touch **>** to select the [→] "Stopwatch" function.
- 3 Touch the II symbol.



The time stops. The symbol changes to ▶ Start.

4 Touch ▶ to start.

The time continues to run. When 90 minutes is reached, the display pulsates and signal sounds. The signal stops when you touch the ✓ symbol. The ♂ symbol on the display goes out. The process has finished.

To switch off the stopwatch:

Call up the timer menu. Touch > to select the $\overline{\bigcirc}$ "Stopwatch" function and touch the \mathbb{C} symbol.

Cooking time

If you set a cooking time for your meal, the appliance switches off heating automatically after the selected time.

You can set a cooking time from 1 minute to 23 hours 59 minutes.

Setting a cooking time

You have set the heating mode and temperature and you have placed your dish in the oven.

- 1 Touch the 🛈 symbol.
- 2 Use > to select the 🕭 "Cooking time" function.

3 Set the desired cooking time using the rotary selector.




4 Press ▶ to start.

The appliance starts. The timer menu is closed. The settings for temperature, heating mode, elapsing time and cooking time end are shown in the display.



During the last minute of the cooking time the remaining time is displayed in an enlarged format.



The appliance switches off after the cooking time has elapsed. The symbol flashes and a signal sounds. The signal stops when you touch the \checkmark symbol, open the appliance door, or switch the function selector to **0**.

Changing the cooking time:

Call up the timer menu. Use > to select the (▲ "Cooking time" function. Change the cooking time using the rotary selector. Press > to start.

Clearing the cooking time:

Call up the timer menu. Use \rightarrow to select the "Cooking time" function. Clear the cooking time with \bigcirc . Return to normal operation with \times .

Cancelling the entire operation: Set the function selector to **0**.

Note: You can also change the heating mode and temperature during the cooking time.

End of cooking time

You can delay the cooking time end to a later time.

Example: it is 14:00. The dish requires a cooking time of 40 minutes. You want it to be ready at 15:30.

Enter the cooking time and delay the cooking time end until 15:30. The electronics system calculates the start time. The appliance starts automatically at 14:50 and switches off at 15:30.

Bear in mind that food which spoils easily should not be left in the cooking compartment for too long.

Delaying the cooking time end

You have set the heating mode, temperature and cooking time.

- 1 Touch the () symbol.
- 2 Use > to select the \bigcirc "Cooking time end" function.



- **3** Set the desired cooking time end using the rotary selector.
- 4 Press ▶ to start.



The appliance switches to standby. The heating mode, temperature, cooking time and cooking time end appear in the display. The appliance starts at the calculated time and switches off automatically when the cooking time has elapsed.

Note: If the **()** symbol flashes: You have not set the cooking time. Always set the cooking time first.

Once the cooking time has elapsed, the appliance switches off. The O symbol flashes and an audible signal sounds. The signal stops early if you touch the \checkmark symbol, open the appliance door, or set the function selector to **0**.

To change the cooking time end:

Call up the timer menu. Use > to select the (), "Cooking time end" function. Set the desired cooking time end using the rotary selector. Press > to start.

To terminate the whole procedure:

Set the function selector to ${\bf 0}.$

Long-term timer

With the appliance in hot air mode, this function keeps the temperature between 50 and 230 °C.

You can keep food warm for up to 74 hours without having to switch the appliance on and off.

Bear in mind that food which spoils easily should not be left in the oven for too long.

Note: To use the long-term timer, you will need to set it to "available" in the basic settings. \rightarrow "Basic settings" on page 23

Setting the long-term timer

- 1 Set the function selector to 🖄.
- 2 Touch the 🕔 symbol.

The default value 24 hrs at 85 °C appears in the display. Press ▶ to start

-or-

Change the cooking time, the cooking time end, the switch-off date and the temperature.



- 3 Changing the cooking time **()**: Touch the **()** symbol. Set the required cooking time using the rotary selector.
- Changing the cooking time end Q:
 Touch the > symbol. Set the required cooking time end using the rotary selector.
- 5 Changing the switch-off date <a>[3]: Touch the > symbol. Set the required switch-off date with the rotary selector. Confirm with ✓.
- 6 Changing the temperature: Set the required temperature with the rotary selector.
- 7 Press ▶ to start.

The appliance starts. \bigcirc and the temperature appear in the display.

The oven and display lighting are switched off. The control panel is locked; no key tone sounds when you touch the touch keys.

Once the set time has elapsed, the appliance stops heating. Turn the function selector to **0**.

Switching off:

To end the process, turn the function selector to **0**.

Individual recipes

It is possible to save up to 50 individual recipes. You can record a recipe. These recipes can be given a name so that they can be called up quickly and conveniently when required.

Recording a recipe

It is possible to set up to 5 phases consecutively while recording at the same time.

1 Turn the function selector to the required type of heating.

The 🖉 symbol will be displayed.

- 2 Touch the 🖉 symbol.
- **3** Use the rotary selector to select a free memory location.
- 4 Touch the $\overset{\text{rec}}{\bullet}$ symbol.

	10		
	rec ●	00.01 min sec	
X		★ 170°°	

- **5** Use the rotary selector to set the required temperature.
- 6 The cooking time will be recorded.
- 7 To record another phase: Turn the function selector to the required type of heating. Turn the rotary selector to set the desired temperature. This will start a new phase.
- 8 Once you have obtained the cooking result you want for the dish, touch the symbol to finish the recipe.
- 9 Enter a name for the recipe in "ABC". → "Entering names" on page 18

Notes

- The appliance will not start recording a phase until it has reached the set temperature.
- Each phase must last at least 1 minute.
- During the first minute of a phase, you can change the type of heating or the temperature.


Programming a recipe

You can programme and save up to 5 preparation phases.

1 Turn the function selector to the required type of heating. Use the rotary selector to set the required temperature.

The wymbol will be displayed.

- 2 Touch the symbol.
- **3** Use the rotary selector to select a free memory location.
- 4 Touch the _ symbol.
- 5 Enter a name for the recipe in "ABC". \rightarrow "Entering names" on page 18
- 6 Use the ➤ symbol to select the first phase. The initial type of heating and temperature are displayed. You can change the type of heating and the temperature using the rotary selectors.



- 7 Use the > symbol to select the time setting.
- 8 Set the required cooking time using the rotary selector.
- 9 Use the > symbol to select the next phase. - or -

If preparation is complete, finish making entries.


10 Save with \checkmark .

- or -

Cancel with \times and exit the menu.

Entering names

1 Enter the name of the recipe in "ABC".



Rotary selec-	Select letters				
tor	A new word always begins with a capital let-				
	ter.				
▶ <u>A</u> ^ă	Press briefly: moves the cursor right				
	Press and hold: shifts to umlauts and spe- cial characters				
	Press twice: accepts the change				
≥Ä	Press briefly: moves the cursor right				
	Press and hold: shift to normal characters				
	Press twice: accepts the change				
X	Deletes letters				

2 Save with \checkmark .


- or -

Cancel with \times and exit the menu.

Note: For entering a name, Latin characters, certain special characters and numbers are available.

Starting recipes

- Set the function selector to any heating mode. The symbol is displayed.
- 2 Touch the wymbol. Use the rotary selector to select the required recipe.
- 3 Press ▶ to start.
 Operation starts. The cooking time starts counting down in the display.
 The settings for each phase are shown in the display.



Notes

- The cooking time does not start counting down until the appliance has reached the set temperature.
- You can use the rotary selector to change the temperature while the recipe is in progress. This does not change the saved recipe.

Change recipe

You can change the settings of a recorded or programmed recipe.

- Turn the function selector to the any type of heating. The wymbol is displayed.
- 2 Touch the 🖉 symbol.
- **3** Use the rotary selector to select the desired recipe.
- 4 Touch the \searrow symbol.
- 5 Use the ➤ symbol to select the desired phase. The programmed type of heating, temperature and cooking time are displayed. You can use the rotary selector or function selector to change the settings.
- 6 Save with ✓.
 or Cancel with × and exit the menu.

Deleting recipes

- Set the function selector to any type of heating. The <u>symbol</u> is displayed.
- 2 Touch the 📱 symbol.
- 3 Use the rotary selector to select the desired recipe.
- 4 Delete the recipe with C.
- 5 Confirm with \checkmark .

Childproof lock

The appliance has a childproof lock to prevent children operating it accidentally.

Notes


- To use the childproof lock, you will need to set it to "available" in the basic settings. → "Basic settings" on page 23
- If there is a power cut after the childproof lock has been activated, the childproof lock may be deactivated when the power comes back on.

Activate the child lock

Prerequisite:

The function selector is set to ${\bf 0}.$

Touch and hold the \bigcirc symbol for at least 6 seconds.




The child lock is activated. The standby screen appears. The \bigcirc symbol is shown at the top of the display.

Deactivating the child lock

Prerequisite:

The function selector is set to ${\bf 0}.$

Touch and hold the $\not\boxtimes$ symbol for at least 6 seconds.



The child lock is deactivated. You can set the appliance as usual.

Home Connect

This appliance can be networked and controlled remotely using a mobile device. The Home Connect app offers extra functions that complement the networked appliance perfectly. If the appliance is not connected to your home network, it can be operated as usual via the display.

The availability of the Home Connect function depends on the availability of Home Connect services in your country. Home Connect services are not available in every country. You can find more information on this at www.home-connect.com.

Notes

- Ensure that you follow the safety instructions in this instruction manual and that you comply with these even when you are away from home and are operating the appliance via the Home Connect app. You must also follow the instructions in the Home Connect app.
- Operating the appliance directly from the appliance always takes priority. It is not possible to operate the appliance using the Home Connect app during this time.
- Refer to the Home Connect documents supplied for more information.

Setting up

To configure settings via Home Connect, you will need to have installed the Home Connect app on a mobile device.

Your appliance will also need to be connected to your home network and to the Home Connect app. You can choose between the following connection types:

- Connection via LAN cable: The appliance is connected to the home network automatically following confirmation on the appliance.
- Connection via WLAN: Establish the connection to your home network and then the connection to the Home Connect app.

Note: The app will guide you through the entire registration process. In case of doubt, follow the instructions in the app.

Installing the app

Install the Home Connect app on your mobile device (e.g. tablet PC or smartphone).

- 1 On your mobile device, go to the App Store (Apple devices) or the Google Play Store (Android devices).
- 2 Enter the search term "Home Connect".

- **3** Select the Home Connect app and install it on your mobile device.
- 4 Launch the app and set up Home Connect access. The app will guide you through the registration process.

Connecting the appliance to your home network (LAN)

The appliance must be connected to your home network using a LAN cable.

The network connection will be established automatically when the appliance is connected to the mains electricity supply for the first time and put into operation.

Connecting the appliance to your home network (WLAN with WPS)

Requirements:

- Your router must have a WPS button. You will find information about this in the manual for your router.
- You need to be able to access your router.
- 1 In the basic settings, select 应 "Home Connect".
- **2** Touch the \searrow symbol.
- 3 Turn the rotary selector to "WLAN".
- 4 Touch the ✓ symbol to confirm.
 A message about the WPS function will appear.
- 5 Touch the \checkmark symbol to continue.
- 6 Turn the rotary selector to "Automatic (WPS)".
- 7 Touch the ✓ symbol to start the connection process.
- 8 Press the WPS button on the router within the next 2 minutes.

If the display shows "Network connection successful", the connection process is complete. Follow the instructions in the app.

Connecting the appliance to your home network (WLAN without WPS)

- 1 In the basic settings, select in "Home Connect".
- **2** Touch the \searrow symbol.
- 3 Turn the rotary selector to "WLAN".
- 4 Touch the ✓ symbol to confirm.
 A message about the WPS function will appear.
- 5 Touch the \checkmark symbol to continue.
- 6 Turn the rotary selector to "Manual".
- Touch the symbol to start the connection process.
 The appliance will set up its own "Home Connect" WLAN network to which the tablet or smartphone must be connected.
- 8 Follow the instructions in the app.

If the display shows "Network connection successful", the connection process is complete. Follow the instructions in the app.

Connecting the appliance to the app

Connect your appliance to the app when setting up Home Connect or connect your appliance to an additional Home Connect account. The Home Connect app can be installed on any number of mobile devices, which can then be connected to the appliance.

Requirements:

- The appliance is connected to the home network.
- The Home Connect app has been installed on the mobile device.
- 1 To connect an additional account, select "Home Connect" in the basic settings.
- 2 Use the rotary selector to select "Connect to app".
- 3 Touch the _ symbol and start the connection process with √.
- 4 Follow the instructions in the app.

If the display shows "Connection to app successful", the connection process is complete.

Remote Start

Remote start must be activated in order to start and operate your appliance via the Home Connect app. If remote start is deactivated, the Home Connect app will only show the operating modes of the appliance and let you configure the settings.

Remote start is automatically deactivated in the following situations:

- The appliance door is opened at least 15 minutes after remote start has been activated.
- The appliance door is opened at least 15 minutes after operation has ended.
- 24 hours after remote start has been activated.

When you start a type of heating using the controls on the appliance, remote start is activated automatically. You can now make changes or start a new programme from your mobile device.

Activating remote start

- 1 Set the function selector to 🖄
- Touch the → symbol.
 The symbol → appears next to the i symbol.

Remote start is activated. You can now start a heating mode via the app on the mobile device and send the desired settings to the appliance.

Touch the 🚿 symbol to deactivate remote start.

Home Connect settings

Home Connect can be adapted to your specific needs at any time.

Note: You will find the Home Connect settings in the basic settings for your appliance. Which settings the display shows will depend on whether Home Connect has been set up and whether the appliance is connected to your home network.

	Basic setting	Permitted settings	Explanation
LAN / WLAN	Connection type	LAN/Wi-Fi	You can switch between connection types (LAN cable and Wi-Fi).
			Follow the instructions for setting up the relevant connection type. \rightarrow "Setting up" on page 20
	Connecting	Connect/disconnect	Switch the network connection on or off as required (e.g. for holiday).
			Network information is retained after the appliance is switched off.After switching on the appliance, you will need to wait for a few seconds while it reconnects to the network.
			In networked standby mode, the appliance requires max. 2 W.
LST.	Connect to app		Start the connection process between the app and the appli- ance.
\mathbf{V}	Software update		As soon as a new software version is available, a message appears in the display. You can install the new software in the Home Connect menu \mathbb{Q} .

<u></u>	Remote control	Activate/deactivate	Access the appliance's functions via the Home Connect app.
(), (),			When deactivated, only the appliance's operating statuses will be displayed in the app.
\bigotimes	Delete network set- tings		All network settings can be deleted from the appliance at any time.
	Appliance information		 The display shows: MAC address COM module Serial number of the appliance Software version
			You can view more information – such as the SSID (network name), although this depends on the connection type – by touching the arrow button.

Remote diagnostics

Customer Service can use Remote Diagnostics to access your appliance if you contact them, have your appliance connected to the Home Connect server and if Remote Diagnostics is available in the country in which you are using the appliance.

Note: For further information and details about the availability of Remote Diagnostics in your country, please visit the service/support section of your local website: www.home-connect.com

About data protection

When your appliance is connected for the first time to a WLAN network, which is connected to the Internet, your appliance transmits the following categories of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the installed WiFi communication module).
- Security certificate of the WiFi communication module (to ensure a secure IT connection).
- The current software and hardware version of your domestic appliance.
- Status of any previous resetting to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use these Home Connect functions for the first time.

Note: Ensure that the Home Connect functions can be used only in conjunction with the Home Connect app. Information on data protection can be accessed in the Home Connect app.

Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance which features Home Connect is in accordance with the basic requirements and the other relevant provisions of the directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at www.gaggenau.com on the product page for appliance in the additional documents.

CE

Hereby, BSH Hausgeräte GmbH declares that the appliance with Home Connect functionality is in compliance with relevant statutory requirements.¹

A detailed Declaration of Conformity can be found online at www.gaggenau.com/gb among the additional documents on the product page for your appliance.¹

UK CA

Only applies to Great Britain 2.4 GHz band (2400–2483.5 MHz): Max. 100 mW

5 GHz band (5150-5350 MHz + 5470-5725 MHz): Max. 100 mW

9)	BE	BG	CZ	DK	DE	EE	IE	EL	ES
	FR	HR	IT	CY	LI	LV	LT	LU	HU
	MT	NL	AT	PL	PT	RO	SI	SK	FI
	SE	NO	CH	TR	IS	UK (NI)			
GHz W	VLAN (Wi-Fi	i): For indo	or use only	/.					
	BA		MD	ME	MK	BS	LIK		LIA

Only applies to Great Britain

Basic settings

Your appliance can be individually adjusted in the basic settings.

- 1 Turn the function selector to **S**.
- 2 Select "Basic settings" using the rotary selector.
- **3** Touch the \checkmark symbol.
- 4 Turn the rotary selector to select the required basic setting.
- 5 Touch the _ symbol.
- 6 Set the basic setting using the rotary selector.
- 7 Save with \checkmark or cancel with \times and exit the current basic setting.
- 8 Turn the function selector to **0** to exit the basic settings menu.

The changes are saved.

-	Basic setting	Permitted settings	Explanation
	Brightness	Level 1, 2, 3, 4, 5*, 6, 7, 8	Sets the display brightness
	Standby screen	On*/Off	Appearance of the standby screen.
G		- Clock - Clock + GAGGENAU logo*	Off: No display. Use this setting to reduce the standby consumption of your appliance.
		- Date - Date + GAGGENAU logo	On: Several displays can be set, confirm "On" with \checkmark and use the rotary selector to select the desired display
		- Clock + date	desired display. The selection is displayed.
	D' 1	- Clock + date + GAGGENAU logo	
	Display	Reduced*/Standard	If the 'Reduced' setting has been selected, only the most important information will be shown on the display after a short time.
	Touch field colour	Grey* / White	Selects the colour of the symbols on the touch fields
5	Touch field tone	Tone 1* / Tone 2 / Off	Selects an audible signal for when a touch field is touched
	Touch field tone vol- ume	Level 1, 2, 3, 4, 5*, 6, 7, 8	Sets the volume of the touch field tone
$\boldsymbol{\succ}$	Rapid heating	On*/off	With rapid heating, the required temperature is reached particularly quickly.
, ,	Preheating signal	On* / Off	The signal tone sounds when the cooking com- partment has heated up to the required temper- ature.
	Signal volume	Level 1, 2, 3, 4, 5*, 6, 7, 8	Sets the volume of the audible signal
	Time format	AM/PM / 24 h*	Display the clock in 24 or 12-hour format
\bigcirc	Time	Current time	Setting the clock
⊘ *	Clock change	Manual* / Automatic	Automatically changes the clock to daylight-sav- ings time. If automatic: Setting the month, day and week for when the time should be changed over. To be set for both summer and winter time.
	Date format	D.M.Y*	Sets the date format
_ <u>31</u> _		D/M/Y	
		M/D/Y	

31	Date	Current date	Sets the date. You can switch between year/ month/day using the symbol > .
	Temperature unit	°C* / °F	Setting the temperature unit
	Language	German* / French [] / English	Select the language for the text display
ABC			Note: The system will restart if the language is changed. This process takes a few seconds. The basic settings menu is then closed.
	Factory settings	Restore appliance to factory settings	Confirm the question "Delete all individual set- tings made and reset to factory settings?" by pressing v or cancel by pressing x.
			Note: Individual recipes will also be deleted if the appliance is restored to factory settings.
			After restoring factory settings, the "Initial set- tings" menu is displayed.
	Demo mode	On / Off*	Only for presentation purposes. The appliance does not heat up in demo mode, all other functions are available.
			The "Off" setting must be activated for normal operation. The setting is only possible in the first 3 minutes after connecting the appliance to the mains.
	Long-term timer	Not available*/Available	Available: Long-term timer can be set. \rightarrow "Long-term timer" on page 17
	Childproof lock	Not available*/Available	Available: The childproof lock can be activated. \rightarrow "Childproof lock" on page 19
\land	Home network	WLAN Connection type	Settings for the connection to the home net-
[0]		Connection	work and the mobile devices.
		Connect to app	Different setting options will be displayed
		\bigcirc Software update	depending on the connection status.
		Remote control	
		\otimes Delete network settings	

Cleaning and maintenance

With thorough care and cleaning your appliance will retain its looks and remain in good order. We will explain here how you should care for and clean your appliance correctly.

▲ Warning – Risk of electric shock!

Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.

A Warning – Risk of burns!

The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.

A Warning – Risk of burns!

Bulbs become very hot when switched on. There is still a risk of burning for some time after they have been switched off. Allow the bulbs to cool down before cleaning the appliance. Switch off appliance light during cleaning.

A Warning – Risk of injury!

Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.

Cleaning agents

Pay attention to the information in the table to avoid damaging the various surfaces by incorrect cleaning agents.

Do not use

- harsh or abrasive cleaning agents
- metal or glass scrapers to clean the glass on the appliance door
- metal or glass scrapers to clean the door seal
- hard abrasive pads or cleaning sponges

Thoroughly rinse out new sponge cloths before use.

Area	Cleaning products
Door panels	Glass cleaner: Clean with a soft cloth or a microfibre cloth. Do not use glass scrapers.
Display	Wipe down using a microfibre cloth or a slightly damp cloth. Do not wipe with a wet cloth.

Area	Cleaning products
Stainless steel	Hot soapy water: Clean using a dishcloth and then dry with a soft cloth. Remove splashes and patches of limescale, grease, starch and albumin (e.g. egg white) immediately. Corrosion can form under these patches or splashes. Special stainless-steel cleaning products are available from our after-sales service or from specialist retailers.
Aluminium	Clean with a mild window cleaning prod- uct. Using a window cloth or a lint-free microfibre cloth, wipe over the surfaces lightly in a horizontal direction.
Cooking compart- ment	Hot soapy water: Clean with a dishcloth and then dry with a soft cloth.
Very dirty cooking compartment	Cleaning gel spray for ovens (order num- ber 00311860 from our after-sales ser- vice or our online shop).
	Please note:
	 The gel must not come into contact with the door seal. Leave for no more than 12 hours. Do not use on hot surfaces. Rinse off thoroughly with water. Follow the manufacturer's instructions.
Glass cover for the cooking compart- ment light	Hot soapy water: Clean with a dishcloth.
Door seal Do not remove.	Hot soapy water: Clean with a dishcloth; do not scrub. Do not use metal or glass scrapers for cleaning.
Cooking accesso- ries	Hot soapy water: Soak and then clean with a dishcloth or brush.
Shelf supports	Dishwasher; see section entitled "Remov- ing the shelf supports"
Telescopic rails (optional acces- sory)	Hot soapy water: Clean with a dishcloth or a brush.Do not soak or clean in the dishwasher.
Baking stone (optional acces- sory)	Remove burnt-on remnants with a brush. Never wet the baking stone to clean it.

Microfibre cloth


The honeycomb microfibre cloth is particularly suitable for cleaning sensitive surfaces such as glass, glass ceramic, stainless steel or aluminium (part number 00460770 from our after-sales service or from our online shop). It removes liquid and greasy deposits in one go.

Removing the rails

The rails can be removed for cleaning.

Detaching the rails


- 1 Lift up the front of the rail and unhook it (figure A).
- 2 Then pull the whole rail forward and remove it (Fig. B).



Clean the rails with cleaning agent and a sponge. For stubborn deposits of dirt, use a brush.

Refitting the rails

- 1 First insert the rail into the rear socket and press it to the back slightly (figure A).
- 2 Then hook it into the front socket (figure B).



The rails fit both the left and right sides. Ensure that, as shown in figure B, the recess is below.

Catalytic cleaning (cleaning aid)

You can order an oven ceiling and an oven back wall, which are coated with a special catalytic enamelling, for the cooking compartment as a spare part. Dirt is removed at high temperatures during the catalytic cleaning.

This process does not clean the non-catalytic components, such as the cooking compartment floor, side walls, inside of the door and glass panel. You can delay the catalytic cleaning switch-off time (for example, if you want the catalytic cleaning to run during the night).

▲ Warning – Risk of burns!

The appliance will become very hot on the outside during the cleaning function. Never touch the appliance door. Allow the appliance to cool down. Keep children at a safe distance.

Preparing catalytic cleaning

- Remove coarse soiling and food remainders from the oven.
- Clean the oven interior base and side walls manually, the door seals, the inside of the door and the glass panel because the catalytic cleaning process does not clean these parts.
- Remove all loose interior parts from the oven interior. There must be no objects left in the interior.
- Close the oven door.

Starting catalytic cleaning

- 1 Set the function selector to **S**.
- 2 The \swarrow^+ symbol is displayed. Confirm with \checkmark .
- 3 The switch-off time, when catalytic cleaning will be finished, is displayed. If required, move the switch-off time with the rotary selector. Confirm with ✓.
- 4 Remove all accessories and coarse soiling from the oven interior. Confirm with √.
- 5 Press ▶ to start. The cleaning time elapses on the display. If the switch-off time has been shifted, the time up to the start of catalytic cleaning elapses in the display. The lamp in the oven interior stays off.



A signal sounds after the catalytic cleaning has expired. A message appears in the display. Leave the appliance to cool down.

Note: The total duration of catalytic cleaning comprises the cleaning time and cooling period. The relevant section of catalytic cleaning time counts down on the display.

What to do in the event of a fault

Malfunctions often have simple explanations. Please read the following notes before calling the after-sales service. ▲ Warning – Risk of electric shock!

Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the aftersales service.

Disruption	Possible cause	Solution
Appliance not working, no display	Plug not inserted	Connect the appliance to the electricity mains
	Power failure	Check whether other kitchen appliances are working
	Fuse defective	Check in the fuse box whether the fuse for the appliance is in working order
	Operating error	Switch off the fuse for the appliance in the fuse box and switch it on again after about 60 seconds
Appliance cannot be started	Appliance door is not quite closed	Close appliance door
The appliance is not working and the display does not respond. 🗇 appears in the display	Childproof lock activated	Deactivating the childproof lock → "Childproof lock" on page 19
Appliance switches off on its own	Safety shut-off: the appliance has not been operated for longer than 12 hours	Confirm the message with v, switch off the appliance and set it again.
Appliance does not heat up, \checkmark appears in the display	Appliance is in demo mode	Deactivate the demo mode in the basic set- tings
Error message "Exxx"		If an error message is displayed, turn the function selector to 0 ; if the display goes out, there was a non-recurring problem. If the error occurs repeatedly or the display remains on, please contact the after-sales service and inform them of the error code.

Power cut

Your appliance can bridge a power cut of a few seconds. Operation continues.

If the power cut was for a longer period and the appliance was in operation, a message appears in the display. Operation is interrupted.

Set the function selector to **0**, then the appliance can be operated again as usual.

Demo mode

The ≠ symbol appears on the display when the appliance is in demo mode. The appliance will not heat up.

Briefly disconnect the appliance from the mains (switch off the household fuse or the circuit breaker in the fuse box). Then deactivate demo mode in the basic settings within 3 minutes. \rightarrow "Basic settings" on page 23

Replacing the oven light bulb

It is possible to replace the oven light. Heat-resistant halogen bulbs (60 W/230 V/G9) can be obtained from the after-sales service or from a specialist retailer. Only use halogen bulbs of the same type.

▲ Warning – Risk of electric shock!

When replacing the cooking compartment bulb, the bulb socket contacts are live. Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

A Warning – Risk of burns!

Bulbs become very hot when switched on. There is still a risk of burning for some time after they have been switched off. Allow the bulbs to cool down before replacing them.

Note: Always remove the new halogen bulb from the packaging using a dry cloth. This increases the service life of the bulb.

Proceed as follows

- 1 Loosen the screw on the lamp cover. Tilt down the lamp cover.
- 2 Pull out the bulb. Insert the new bulb.
- 3 Tilt the lamp cover up and screw it back on.
- 4 Switch the circuit breaker back on.

Replacing the glass cover

If the glass cover in the oven is damaged, it must be replaced. You can obtain covers from the after-sales service. Please supply your appliance's E number and FD number.

After-sales service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find an appropriate solution, also in order to avoid after-sales personnel having to make unnecessary visits.

E number and FD number

When calling us, please give the full product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate bearing these numbers can be found when you open the appliance door.

	FD:	Z-Nr:
Type:		

To save time, you can make a note of the number of your appliance and the telephone number of the after-sales service in the space below, should it be required.

E no.

FD no.

After-sales service 🗇

Please note that a visit from an after-sales service engineer is not free of charge, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

To book an engineer visit and product advice

- **GB** 0344 892 8988 Calls charged at local or mobile rate.
- IE 01450 2655
 0.03 € per minute at peak.
 Off peak 0.0088 € per minute.
- AU 1300 368 339
- NZ 09 477 0492

Trust the expertise of the manufacturer, and rest assured that the repair will be carried out by trained service technicians using original spare parts for your domestic appliance.

This product contains light sources from energy efficiency class G.

Tables and tips

Notes

- Always preheat the appliance. This will produce the best cooking results. The cooking times specified refer to a preheated appliance.
- The values specified are intended as a guide. The actual cooking time depends on the quality and temperature of the food before cooking, as well as its weight and thickness.
- The tables list temperature and/or time ranges. Try the lowest value to start with. You can always choose a longer time next time, if required.
 A lower temperature results in more even browning. If necessary, set a higher temperature.
- The figures listed refer to average quantities of food for four people. If you wish to cook a larger quantity of food, you should allow for extra cooking time.
- Use the cookware specified. If you use other cookware, the cooking times may be longer or shorter.
- You can use any heat-resistant cookware. Place the cookware in the centre of the wire rack. For large roasts, you can also use the grill tray or glass dish.
- Do not place too many items close together on wire racks or baking trays. This is the only way to ensure optimal heat circulation.
- To prepare bulky food items, you can remove the shelf supports at both sides. Place the wire rack directly onto the bottom of the cooking compartment and place the food or roasting dish onto the wire rack. Do not place the food or roasting dish directly onto the enamel bottom of the cooking compartment.
- Open the door of the preheated oven for a short time only when placing food inside the cooking compartment.
- The figures given for the level refer to the rack level (counting from the bottom) in appliances with four rack levels. The figures in brackets refer to appliances with five rack levels.
- Once you have taken glass cookware out of the oven, set it down on a dry trivet or heat-proof mat; never set it down on a cold or wet surface. Otherwise, the glass may crack.
- Some operating modes are not available on all oven models or are only available in conjunction with certain optional accessories.

Eco hot air:

Energy-saving hot air mode for cakes, meat, bakes and gratins. Optimal use is made of the residual heat. Convenience functions remain switched off (e.g. the interior lighting). The interior temperature can only be displayed while the appliance is heating up. Do not preheat the oven.

Make sure that the cooking compartment is cold and that there is nothing already in there when you place the food inside. Then start the specified cooking time. Always keep the appliance door closed when cooking. This prevents heat loss.

Full surface grill and full surface grill + circulated air:

With these operating modes, there may be a temperature difference between the temperature you have set and the actual temperature inside the oven. This is because grilling and browning are fast cooking processes that require high temperatures. Consequently, for browning and roasting, a higher temperature than is actually needed on the surface of the food is selected.

Vegetables

- Oven-roasted or oven-baked vegetables are a good alternative to pan-fried vegetables. The different flavours become more concentrated and, because the vegetables are roasted, they have a very distinctive taste. In addition, very little fat is required to prepare the vegetables.
- Clean and prepare the vegetables and mix them with a little oil in a bowl. Place them in a heatresistant baking dish or tin or in the glass dish/grill tray and spread them out evenly.
- Mix them thoroughly at least once during the cooking process. Once they are cooked, season them and sprinkle them with fresh herbs to taste.
- Vegetables are good as a hot or cold starter or vegetarian main course, or as an accompaniment to meat and fish.
- Use an ovenproof dish for small portions (for 2 -3 people) and place it on the wire rack. If you use the glass dish/grill tray, the food will start to burn or dry out.
- In addition, always follow the manufacturer's instructions for pre-cooked and frozen products.

Meal	Accessories	Level	Temperature in °C	Type of heating	Cooking time (mins)	Comments
Vegetable skewers	Wire rack + grill tray	3 (4)	220		24*	Shorten the wooden skewers or leave them to soak in water overnight to pre- vent them from charring.
						Recipe tip: Peppers, onions, sweetcorn (pre-cooked), cherry tomatoes, cour- gettes
Green asparagus, grilled	Glass dish/ grill tray	3 (4)	220		6 - 10*	Recipe tip: Season with onion, oil, vine- gar, salt and pepper.
Root vegetables	Glass dish/	3 (4)	200	4	30*	Recipe tip: Season carrots, celery,
	grill tray	3 (4)	250	0000	15 - 20*	swede and beetroot with oil, garlic, salt and pepper.
Sliced pumpkin	Glass dish/ grill tray	3 (4)	200	4	20 - 30*	Recipe tip: Season with oil, garlic, gin- ger, cumin, salt and pepper.
Antipasti	Glass dish/	3 (4)	200	\$	30*	Recipe tip: Drizzle balsamic vinegar over
	grill tray	3 (4)	250	0000	15 - 20*	the vegetables while they are still hot, and season them.
Escalivada (Mediterranean oven-roasted vegeta- bles)	Ovenproof dish	4 (5)	250		15*	Recipe tip: Aubergines, onions, toma- toes, peppers, oil. Delicious hot or cold.
Ratatouille	Glass dish/ grill tray	3 (4)	200		30 - 40*	Recipe tip: Sprinkle with parmesan just before serving.
Oven-roasted toma- toes	Ovenproof dish	2 (3)	120	<u> </u>	60	Recipe tip: Place cherry tomatoes or sliced tomatoes, rosemary and garlic into the baking dish and drizzle with oil and a little honey.
						If you wish, you can blanch the tomatoes and skin them before roasting them in the oven.
Chicory	Ovenproof dish	2 (3)	180	J.	25 - 30	Recipe tip: Halve, season, wrap in boiled ham, pour cream or béchamel sauce over the top and sprinkle with cheese.
		2 (3)	190	S e	45 - 50	No need to preheat; do not open the appliance door.
Stuffed peppers, vegetarian	Ovenproof dish/roaster	2 (3)	190		50	Recipe tip: Stuff with boiled rice, soft wheat or lentils and onion, cheese, herbs and seasoning/spices.

Meal	Accessories	Level	Temperature in °C	Type of heating	Cooking time (mins)	Comments
Stuffed courgettes, vegetarian	Glass dish/ grill tray	2 (3)	180		40	Recipe tip: Stuff with grated carrot, spring onions, goat's cheese, garlic, thyme, salt and pepper, and sprinkle with parmesan.
Vegetable bake	Ovenproof dish	2 (3)	180	4	40 - 50	Pre-cook/blanch vegetables and other ingredients.
Veggie burgers, frozen	Baking tray + grease- proof paper	2 (3)	220	\$	12 - 15*	

Side dishes and meals

- The best known oven-cooked side dishes are potato-based, such as potato gratin. However, you can also obtain excellent results when oven-cooking side dishes that are normally pan-fried, e.g. potato fritters and fried potatoes. The advantages of this preparation method: You can prepare relatively large quantities of food at the same time, the cooking smells do not spread so far in the room, and the food can be prepared using less fat.
- Another highly versatile oven-cooked side dish is cheese. It is a very good addition to vegetarian dishes in particular; depending on the preparation method, you can also serve cheese as a starter or finger food.
- Grilled dishes such as bakes and gratins are particularly well suited to being prepared in the oven. Dishes with a dough or pastry base, e.g. pizza and savoury flan, and egg dishes with a filling, e.g. tortilla, are also suitable.
- Use a heat-resistant baking dish or tin for small portions (2 - 3 people) and place it on the wire rack. If you use the glass dish/grill tray, small portions will start to burn or dry out.
- In addition, always follow the manufacturer's instructions for pre-cooked and frozen products.

Meal	Accessories	Level	Temperature in °C	Type of heating	Cooking time (mins)	Comments
Side dishes						
Potatoes on a bed of coarse salt	Ovenproof dish	2 (3)	200		40 - 60*	Fill the ovenproof dish with 2 cm of sea salt. Place small potatoes into the dish with their skins on and brush them with olive oil.
Potato wedges	Baking tray + greaseproof paper	2 (3)	200	ş	15*	Recipe tip: Cut the potatoes into wedges and season them with olive oil, paprika and salt.
Chips, fresh	Baking tray + greaseproof paper	3 (4)	200	Se.	15 - 20*	Recipe tip: Cover with a little oil; season with salt and paprika or curry powder after cooking.
Chips, frozen	Baking tray + greaseproof paper	3 (4)	220	Ş	14*	
Potato gratin	Ovenproof	2 (3)	180	4	35	
	dish	2 (3)	190	÷	55 - 60	No need to preheat; do not open the appli- ance door.
Potato pancakes	Baking tray	2 (3)	175	4	20 - 30*	Grease the baking tray thoroughly, squeeze
	<u> </u>	2 (3)	200		20 - 30*	the excess liquid out of the potato pancake mixture and brush with a little oil. Turn once.

Meal	Accessories	Level	Temperature in °C	Type of heating	Cooking time (mins)	Comments
Roast potatoes	Grill tray	2 (3)	180	J _p	30 - 45*	Low-fat preparation. Spread evenly across the grill tray and mix thoroughly several times.
Goat's cheese	Glass dish/	2 (3)	220	4	8 - 10	Either goat's cream cheese or goat's cam-
wrapped in bacon	baking tray	3 (4)	220	00000	8 - 10	embert can be used.
Goat's cheese with	Glass dish/	2 (3)	200	4	8	Recipe tip: Drizzle lavender honey over the
honey	baking tray	3 (4)	200		8	goat's cream cheese or goat's camembert and sprinkle with pine nuts.
Baked camembert, coated with bread- crumbs, fresh	Baking tray + grease- proof paper	2 (3)	180	5	15 - 20	Bake until the breadcrumb coating rises in the centre.
Baked camembert,	Baking tray	2 (3)	180	4	15 - 20	Bake until the breadcrumb coating rises in
coated with bread- crumbs, frozen	+ grease- proof paper	2 (3)	200		15	the centre.
Mozzarella sticks, frozen	Baking tray + grease- proof paper	2 (3)	180	30	10	
Feta	Baking tray	2 (3)	250	23 23	12	Recipe tip: Place in a baking dish with oil, tomatoes, onion, garlic and rosemary, and season with salt and pepper.
Oven-baked cheese, fresh	Baking tray	2 (3)	180	ş	20	After 10 minutes, cut a cross into the soft cheese and break open. If possible, the dish should be not much larger than the cheese so that the cheese does not run.
Meals						
Tortilla	Ovenproof dish	2 (3)	160		25	Recipe tip: With paprika, olives, onion, Ser- rano ham and Manchego cheese.
Farmer's omelette	Ovenproof dish	2 (3)	160	5	40	Recipe tip: With green and white asparagus; also add gravlax.
Frittata	Ovenproof dish	2 (3)	190		45 - 50	Recipe tip: With spinach, onion and prawns.
Enchiladas, grilled	Glass dish/ grill tray	2 (3)	200		15 - 20	
Lasagne	Ovenproof dish	2 (3)	175	5	35	Recipe tip: Traditional or vegetarian with grilled vegetables and buffalo mozzarella.
		2 (3)	180 - 190	S e	55 - 60	No need to preheat; do not open the appli- ance door.
Macaroni cheese	Ovenproof dish	2 (3)	180 / 220	5	10 - 20	To obtain a crust on the cheese, increase the temperature to 220 °C after 10 minutes and leave to brown for a further 10 minutes.
Cheese spätzle (Swabian noodle	Ovenproof dish	2 (3)	180 / 220	4	30	Gradually layer the freshly cooked spätzle in the dish, sprinkling each layer with cheese.
dish)						Then top the dish with cheese and roasted onion, raise the temperature to 220 $^{\circ}$ C and cook for 5 minutes.
Spring rolls, frozen	Baking tray + greaseproof paper	2 (3)	225	₫ <u>n</u>	18 - 20*	
Mini spring rolls, frozen	Baking tray + greaseproof	2 (3)	225	J.	10*	
	paper					
Pizza, fresh	Baking tray	2 (3)	230 - 250		10 - 15	Lightly oil the baking tray.

			in °C	heating	time (mins)	
	Baking tray	2 (3)	230	4	6 - 8	
	+ greaseproof paper	2 (3)	230		6 - 8	-
Pizza, frozen	Wire rack	2 (3)	200	4	11 - 13	
		2 (3)	220		11 - 13	-
American pizza (deep pan), frozen	Baking tray	2 (3)	200		20 - 24	No need to pre-heat.
Tarte flambée, fresh	Baking tray	2 (3)	250		8 - 10	Recipe tip: Traditional or with goat's cheese, Parma ham, figs and spring onions.
pre-baked	Baking tray + greaseproof paper	2 (3)	250	5	7	
Tarte flambée,	Wire rack	2 (3)	200	4	10 - 12	
frozen		2 (3)	230		8 - 10	-
	Tart tin or dish	2 (3)	200		20 + 20	Pre-bake the base for 20 minutes, pour the mixture onto the base and then bake for a further 20 minutes.
Onion tart	Baking tray	2 (3)	200		30 - 40	

Fish

- For food hygiene reasons, fish should have a core temperature of at least 62 - 70 °C after cooking. This is also the ideal cooking temperature.
- Do not season the fish with salt until it is fully cooked. This ensures that the natural flavour is maintained and that less water is drawn out of the fish.
- Use a small amount of oil to grease the wire rack or baking tray so that the fish does not stick to it.
- For fillets with skin: Place the fish on the rack or tray with the skin side up this helps to hold the fish together and maintain its flavour.
- Shorten the wooden skewers or, before skewering the ingredients, leave the skewers to soak in water overnight to prevent them from charring.
- In addition, always follow the manufacturer's instructions for pre-cooked and frozen products.

Meal	Accessories	Level	Temperature in °C	Type of heating	Cooking time (mins)	Comments
Prawn skewers, fresh	Wire rack + grill tray	3 (4)	180	00000	10*	
Prawn skewers, frozen	Wire rack + grill tray	3 (4)	180		12*	
Fish kebabs	Wire rack + grill tray	3 (4)	200		12*	Use firm types of fish, e.g. salmon, coley, ocean perch and cod.
Trout, whole	Baking tray	3 (4)	200 - 220		16*	Recipe tip: Stuff with lemon, garlic and pars- ley.
Sea bream, whole	Wire rack + grill tray	3 (4)	200 - 220		20 - 25*	Recipe tip: Stuff with lemon, garlic and thyme, or use mint for a summery touch.
	Baking tray	3 (4)	190	4	20 - 25*	[—] Make a diagonal incision into the skin of the sea bream.
Salmon steak	Wire rack + grill tray	3 (4)	250	E C C C C C C C C C C C C C C C C C C C	10 - 12	Recipe tip: Marinate in a mixture of lime, salt, pepper and garlic.
	Baking tray	2 (3)	200	\$	10 - 12	_

Meal	Accessories	Level	Temperature in °C	Type of heating	Cooking time (mins)	Comments
Tuna steak	Baking tray	2 (3)	200	4	8 - 10	Recipe tip: Season Asian-style with soy sauce, sesame oil, ginger, honey, garlic, chilli and coriander seeds.
Fish fingers, frozen	Baking tray + grease- proof paper	2 (3)	220	5	15 - 17*	
Squid rings, frozen	Baking tray + grease- proof paper	2 (3)	220		8 - 12	

Meat

- Leaving meat to rest: Leave the meat to rest for a further 10-15 minutes after cooking. This gives the meat a chance to "relax". The meat juices begin to circulate less, and when the meat is cut, less juice is lost. Large pieces of meat, e.g. joints, can be left to rest in the oven. Smaller pieces of meat, e.g. steaks, should be wrapped in aluminium foil and left to rest outside the oven.
- For small portions (two to three people), it is a good idea to use a heat-resistant baking dish or tin so that the food does not begin to burn or dry out.
- Use the grill tray or roasting dish for a large joint of meat and for preparation methods that involve adding a lot of liquid to the joint.

- For best results, leave meat to marinate overnight and remove the marinade before roasting or grilling, e.g. using the back of a knife or a spoon. Otherwise, the herbs and spices will burn.
- If the joint of meat has become too dark in colour and the skin is burnt in places, reduce the set temperature the next time you cook a joint and check the rack level.
- If the joint is cooked but the sauce is slightly burnt, use a smaller roasting dish the next time you cook a joint and add more liquid. If the sauce is too watery, use a larger roasting dish and add less liquid.

Meal	Accessory/ ies	Level	Tempera- ture in °C	Type of heating	Cooking time (mins)	Comments
Beef						
Roast beef (1.5 kg)	Glass dish/ grill tray	2 (3)	180	4	90 - 120*	
Rump steak, medium	Glass dish/	2 (3)	200	4	30	
rare (500 g)	grill tray	2 (3)	200	÷	45 - 50	No need to preheat; do not open the appli- ance door.
Roast beef/sirloin steak (1 kg) – rare	Glass dish/ grill tray	2 (3)	230 / 180	5	25 - 35**	Recipe tip: Delicious with Béarnaise sauce or sliced cold with remoulade and roast potatoes.
– medium rare	Glass dish/ grill tray	2 (3)	230 / 180	\$	30 - 40**	_
– well done	Glass dish/ grill tray	2 (3)	230 / 180	\$	50 - 60**	-
Pork						
Fillet of pork, whole	Glass dish/ grill tray	2 (3)	230 / 180	\$	20 - 25**	Recipe tip: Marinate in a mixture of oil, garlic and parsley.
Fillet of pork	Glass dish/	2 (3)	180	4	30	
(250 g)	grill tray	2 (3)	180	e	40 - 45	No need to preheat; do not open the appli- ance door.

* Sear on all sides in a frying pan/roasting dish on the hob first.

** Sear the meat at a high temperature; set the lower temperature after 15 - 20 minutes.

*** Cook the meat at a low temperature; set it to cook at the higher temperature for the last 15 - 20 minutes.

Meal	Accessory/ ies	Level	Tempera- ture in °C	Type of heating	Cooking time (mins)	Comments
Pork medallions	Glass dish/ grill tray	2 (3)	180	da P	12 - 15*	Recipe tip: Just before you take them out the oven, add a knob of butter and a sprig of rosemary to the glass dish/grill tray and cook all together for a little longer in the oven.
Joint of pork – leg (1 kg)	Glass dish/ grill tray	2 (3)	230 / 180	de.	45 - 50**	
Joint of pork – neck	Glass dish/	2 (3)	230 / 180	4	85 - 95**	
(1.5 kg)	grill tray	2 (3)	230 / 180	S. S	70 - 80**	-
Joint of pork with crispy skin/roast pork with crackling (1.5 kg)	Wire rack + grill tray	2 (3)	180 / 200	G	60 - 70***	
Knuckle of pork	Wire rack + grill tray	2 (3)	150 / 200	See and the second seco	40 - 45***	Score the skin diagonally in both directions so that it is cross-hatched. This will make it nice and crispy.
Smoked pork (1 kg)	Glass dish/ grill tray	2 (3)	180 / 160	4	50 - 60**	
Rolled roasting joint	Glass dish/ grill tray	2 (3)	230 / 180	\$	65 - 70***	
	Wire rack + grill tray	2 (3)	230 / 180	e e e e e e e e e e e e e e e e e e e	75 - 80***	
Veal						
Joint of veal (1.5 kg)	Glass dish/ grill tray, roaster	2 (3)	180	5	50 - 60*	
Veal knuckle	Glass dish/ grill tray, roaster	2 (3)	150 / 180	B	50 - 60***	
Veal loin	Glass dish/ grill tray, roaster	2 (3)	160 - 170	5	20	
Stuffed breast of veal	Glass dish/ grill tray, roaster	2 (3)	120 - 130	\$	120	
Game						
Wild boar joint	Glass dish/ grill tray, roaster	2 (3)	170	\$	60 - 90*	Recipe tip: Marinate overnight in a mixture of oil, garlic, mustard and herbes de Provence.
Leg of roe venison	Glass dish/ grill tray, roaster	2 (3)	170 - 180	5	60 - 80	
Saddle of venison	Glass dish/	2 (3)	165 - 175	4	20	_
	grill tray, roaster	2 (3)	165 - 175		20 - 25	_
Saddle of rabbit	Glass dish/ grill tray, roaster	2 (3)	180	5	15 - 25*	Recipe tip: Marinate in a mixture of garlic, rosemary, olive oil and high-quality balsamic vinegar.

* Sear on all sides in a frying pan/roasting dish on the hob first.

** Sear the meat at a high temperature; set the lower temperature after 15 - 20 minutes.

*** Cook the meat at a low temperature; set it to cook at the higher temperature for the last 15 - 20 minutes.

Meal	Accessory/ ies	Level	Tempera- ture in °C	Type of heating	Cooking time (mins)	Comments
Leg of lamb – medium rare	Glass dish/ grill tray, roaster	2 (3)	180 - 190	J.	100*	Recipe tip: Marinate overnight in a mixture of olive oil, garlic, rosemary and sliced lemon.
- well done	Glass dish/ grill tray, roaster	2 (3)	180 - 190	5	120*	_
Lamb knuckle	Glass dish/ grill tray, roaster	2 (3)	180 - 200	\$	35 - 45	
Miscellaneous						
Meatballs (80 g per ball)	Baking tray + grease- proof paper	2 (3)	200	<u>4</u>	30 - 35	The flatter the meatballs, the faster they cook. Easy to make in large quantities.
Meatballs, lightly fried (80 g each)	Baking tray + grease- proof paper	2 (3)	200	4	20	For nicely browned yet juicy meatballs, fry them lightly in the frying pan first before put- ting them in the oven.
Meatballs (25 g per ball)	Baking tray + greaseproof paper	2 (3)	200	5	25 - 30	Recipe tip: Easy to make into a meal, e.g. meatballs with tomato sauce, Swedish meat balls and Königsberger Klopse (Prussian meatballs in a white sauce with capers).
Meatballs, lightly fried (25 g each)	Baking tray + greaseproof paper	2 (3)	200	5	15	Recipe tip: Place meatballs made from minced lamb or rabbit on skewers and serve with mint yoghurt or fig mustard.
Meat loaf, fresh (700 g)	Wire rack + grill tray	2 (3)	160	4	60	
Bacon strips (fried bacon), thin	Baking tray + greaseproof paper	3 (4)	180	5	8 - 10	After removing from the oven, place on kitchen towel to soak up the fat.
Bacon strips (fried bacon), thick	Baking tray + greaseproof paper	3 (4)	190	5	8 - 12	
Peppers stuffed with minced meat	Ovenproof dish/roaster	2 (3)	175	4	55 - 60	Recipe tip: Stuff with minced meat and cook in tomato sauce.

** Sear the meat at a high temperature; set the lower temperature after 15 - 20 minutes.

*** Cook the meat at a low temperature; set it to cook at the higher temperature for the last 15 - 20 minutes.

Poultry

- Poultry will turn out particularly crispy and brown if you baste it towards the end of the roasting time with butter, salted water, drained fat or orange juice.
- When cooking duck or goose, pierce the skin underneath the wings to allow the fat to run out.
- Use a roasting dish or another heat-resistant baking dish or tin for dishes that involve adding a lot of liquid to the roast. The same applies if a lot of fat is likely to drain from the food, e.g. for roast goose.

Meal	Accessories	Level	Temperature in °C	Type of heating	Cooking time in min.	Comments
Duck, whole (1.5 - 2 kg)	Wire rack + Grill tray/ roasting dish	2 (3)	160/180		75*	Recipe tip: Stuff with oranges, apples o dried fruit.
Duck breast	Roasting dish/oven- proof dish	2 (3)	190	\$	25 - 35	Score the skin diagonally in both directions so that it is cross-hatched.
Goose, whole (5 kg)	Wire rack +	2 (3)	160/190	*	110 - 130*	Recipe tip: Stuff with apples, onions and
	Grill tray/ roasting dish	2 (3)	160/190		110 - 130*	marjoram, and pin the opening closed with a cocktail stick or similar sharp item
Turkey, whole	Wire rack +	2 (3)	200/160	*	120 - 180*	
	Grill tray/ roasting dish	2 (3)	200/160		120 - 180*	-
Chicken, whole	Wire rack +	2 (3)	190	4	70 - 80	Preheating.
(1 kg)	Grill tray	2 (3)	190	see all all all all all all all all all a	70 - 80	-
(in accordance with EN 60350-1)						
Chicken drumstick	Wire rack +	3 (4)	220	0.000	30**	Recipe tip: Asian marinade with soy
	Grill tray	3 (4)	220	B.	30**	sauce, honey, chilli, garlic, ginger, cumin sweet lime zest and coriander.
Chicken leg	Wire rack +	3 (4)	220		30**	After the leg is turned, the side with more
	Grill tray	3 (4)	220	E C C C C C C C C C C C C C C C C C C C	30**	skin should be at the top. This makes it nice and crispy.
						Marinate in a mixture of oil, rosemary, sliced lemon and garlic
Chicken breast	Wire rack + Grill tray	2 (3)	200	4	20 - 25	Recipe tip: Rub with tandoori paste before cooking.
		2 (3)	200	÷	50	No need to preheat; do not open appliance door.
Chicken nuggets, frozen	Baking tray + Grease-	2 (3)	200	4	15**	
Quail breast	proof paper Baking tray	3 (4)	220	e e e e e e e e e e e e e e e e e e e	10 - 12	Baste with oil and seasoning/spices, e.g
-				W M M		paprika, thyme, juniper and garlic.
Quail, whole (150 g per bird)	Wire rack + Grill tray	3 (4)	200		20 - 25	Baste with oil and seasoning/spices, e.g paprika, thyme, juniper and garlic.

** Turn food after half the cooking time has elapsed.

Grilling and roasting

- Do not grill food with the oven door open.
- For grilling, use the grill tray with the wire insert (depending on the model, this may be an accessory or an optional accessory). Pour approximately 100 ml water into the grill tray; this will catch the meat juices so that the oven stays clean. If you pour in too much water, this may alter the cooking result because too much steam will be produced.
- The pieces of food to be grilled should be of roughly the same thickness (at least 2 to 3 cm). This will allow them to brown evenly and remain succulent and juicy. Never add salt to meat before grilling it. Place the food to be grilled directly on the wire rack.
- If you use wooden skewers, they may char. To prevent this, shorten them as far as possible, leave them to soak in water overnight before skewering the ingredients or use metal skewers.
- For small quantities, use the energy-saving "Compact grill" heating function. With this heating function, only the centre part of the grill is heated. Place the food to be grilled in the centre of the wire rack.

Dish	Accessories	Level	Recom- mended tempera- ture in °C	Type of heating	Cooking time (mins)	Comments
Pork belly,	Wire rack +	2 (3)	230		18–20*	
sliced	grill tray	2 (3)	230	Ser	18–20*	_
Shish kebab	Wire rack + grill tray	3 (4)	190	B	16*	
Bratwurst (German sausage)	Wire rack + grill tray	3 (4)	270	00000	10*	
Merguez sausage	Wire rack + grill tray	3 (4)	250	S S	12*	
Spare ribs,	Wire rack +	3 (4)	200-220		24*	
pre-cooked	grill tray	3 (4)	200-220	- Aline - Alin	24*	
Spare ribs,	Wire rack +	3 (4)	220		40*	Recipe tip: Place in a mixture of oil, mustard,
raw	grill tray	3 (4)	220	4 F	30*	balsamic vinegar, honey, garlic, Worcester sauce, tomato purée and Tabasco sauce.
Chicken satay	Wire rack + grill tray	3 (4)	250	E Constantino de la constant	10–14*	Serve with satay sauce.
Halloumi cheese (grill cheese)	Wire rack + grill tray	3 (4)	250	G.	5–8	Halloumi is a semi-hard cheese used in Turk- ish and Greek cooking. It is excellent grilled.
Toasting bread (Appliance width: 60 cm)	Wire rack	3	200	00100100	2:30–3	Preheat for up to 5 minutes. Stay by the appliance so that the toast does not brown too much. Do not grill food with the oven door open.
Toasting bread (Appliance width: 76 cm)	Wire rack	4	200	001000	2–2:30	Preheat for up to 5 minutes. Stay by the appliance so that the toast does not brown too much. Do not grill food with the oven door open.
Toast Hawaii	Baking tray + grease- proof paper	3 (4)	190	G.	8–10**	
Croque monsieur	Baking tray + grease- proof paper	3 (4)	190	H	8–11**	

** Brown to the level you require.

Dish	Accessories	Level	Recom- mended tempera- ture in °C	Type of heating	Cooking time (mins)	Comments
Croutons	Baking tray	2 (3)	180	de.	15*	Recipe tip: Mix fresh white bread with olive oil, garlic and rosemary leaves.
						Avoid using too much oil and wait until you are ready to serve before pouring it on; oth- erwise, the bread cubes will become satu- rated. Turn several times.
Browning meringue	Springform cake tin	2 (3)	220–250		4–5**	Stay by the appliance so that the meringue does not brown too much.
Prunes wrapped in bacon	Baking tray + grease- proof paper	3 (4)	200		8–10	Equally delicious with dates or apricots.
* Turn the food ha		0				
** Brown to the level	vel you require.					

Baked items

- We recommend using dark-coloured metal baking tins as these absorb heat more effectively. Place the baking tin in the centre of the wire rack.
- If you are baking tray bakes without greaseproof paper, lightly grease the baking tray beforehand.
- Small baked items, e.g. cream puffs, biscuits and puff pastry parcels, can be baked on two levels, 1+3 or 2+4.
- If you are baking on more than one level, it is normal for food on baking trays placed in the oven at the same time to be ready at different times. Leave the food on the baking trays lower down in the oven to cook for a little longer, or place them in the appliance earlier next time.
- Before cutting the baked items, leave them to cool on a wire rack.
- If the baked items are too dark on the bottom, place them a level up and select a lower temperature.

If the baked items are too dark on the top, place them a level down, select a lower temperature and extend the baking time a little.

• If the cake is too dry, set the temperature a little higher. If the cake remains uncooked in the middle, set a lower temperature.

Baking times cannot be reduced by setting a higher temperature; it is better to set the temperature a little lower.

- If the cake collapses, use less liquid or set the temperature 10 °C lower. Do not open the oven door too soon.
- If the cake only rises in the middle, grease the sides of the baking tin.

- Do not remove the biscuits from the baking tray; place the baking tray back into the hot oven for a short period and remove the biscuits whilst they are still hot.
- If the cake does not come away from the tin when you are trying to turn it out, carefully slide a knife around the sides to loosen it. Turn the cake tin upside down again and cover it several times with a cold, wet cloth. Next time, grease the tin well and sprinkle some bread crumbs into it.
- In addition, always follow the manufacturer's instructions for pre-baked and frozen products.

Dish	Accessories	Level	Temperature in °C	Type of heating	Cooking time (mins)	Comments
Cakes						
Cheesecake	Springform	1 (2)	160–165	\$	70–75	
	cake tin	1 (2)	160–165		70–75	-
		1 (2)	160–165	*	85–90	-
		1 (2)	160–165		80-90	-
		1 (2)	160–165	5	40–45	Low-cheese cheesecake with 50% quark mixture.
Sponge cake	Springform	2 (3)	160–170	\$	50-60	
	cake tin	2 (3)	160–170		50-60	-
Loaf cake	Loaf tin	2 (3)	160–170	4	60–65	To ensure even browning, place the tin
		2 (3)	160–170		55-60	lengthways in the cooking compartment.
Bundt cake, ring cake	Ring cake tin	1 (2)	165	-	30	Recipe tip: Stick to a traditional Bundt cake recipe or add bacon and walnuts.
		1 (2)	170	S e	55	No need to preheat; do not open the appl ance door.
Tray bakes	Baking tray	2 (3)	165–170	\$	20–30	Lightly grease the baking tray.
		2 (3)	165–170		40–50	-
Swiss roll	Baking tray + greaseproof paper	2 (3)	190	J <u>a</u>	6	Turn it out while still hot onto a piece of greaseproof paper sprinkled with sugar, then roll it up.
Sponge base	Springform cake tin	2 (3)	150	J _p	40-45	Line a springform cake tin with grease- proof paper.
Yeast tray bakes	Baking tray	2 (3)	165	4	30-35	Recipe tip: Top with plums, figs or onion
-		2 (3)	165		30–35	and ham.
Fruit flan with short-	Tart tin or	2 (3)	165	4	40-50	Recipe tip: Top with strawberries or apri-
crust pastry	dish	2 (3)	170		40-50	cots and marzipan.
		2 (3)	165	*	45-55	-
Tart	Tart tin or	2 (3)	190	\$	30-40	French flan with a shortcrust pastry base,
	dish	2 (3)	190		30-40	e.g. tarte aux pommes, tarte tatin, tarte au
		2 (3)	190	*	40-45	[–] chocolat and tarte au citron.
		2 (3)	190		45-50	For light-coloured tart tins or dishes.
Strudel made from puff pastry	Baking tray + grease- proof paper	2 (3)	200	5	20–25	Recipe tip: Fill with custard and cherries or apples.
Apple pie	20 cm	2	160**	4	90–105	Preheat
(in accordance with EN60350-1)	springform cake tin					
(Appliance width: 60 cm)	20 cm springform cake tin	1	160**		90–100	Preheat
Apple pie	20 cm	3	160**	*	85–100	Preheat
(in accordance with EN60350-1)	springform cake tin					
(Appliance width: 76 cm)	20 cm springform cake tin	2	160**		100–110	Preheat

* Preheat the appliance to the specified temperature. Turn the temperature down to the second specified temperature when placing the food in the oven.

Dish	Accessories	Level	Temperature in °C	Type of heating	Cooking time (mins)	Comments
Water sponge cake	26 cm	2	160**	\$	22–30	Preheat
(in accordance with EN60350-1)	springform cake tin					
(Appliance width: 60 cm)	26 cm springform cake tin	2	160**		20–30	Preheat
Water sponge cake	26 cm	3	160**	4	22–30	Preheat
(in accordance with EN60350-1)	springform cake tin					
(Appliance width: 76 cm)	26 cm springform cake tin	3	160**		25–30	Preheat
Small baked items						
Cream puffs, eclairs	Baking tray	2 (3)	180	4	35	Recipe tip: Fill with vanilla custard, choco-
	+ grease-	2 (3)	180		40	late mousse, fruit cream or mocha cream.
	proof paper	2 (3)	180	*	35	
Biscuits,	Baking tray	2 (3)	160-170	*	15	-
piped cookies	Daking trav	2 (3)	160-170		18 15–20	
Small baked puff- pastry items	Baking tray + greaseproof paper	2 (3)	200		15-20	
Filled puff pastry parcels	Baking tray + greaseproof	3 (4)	200	ş	15	Recipe tip: Fill with ham and cheese or apples and raisins.
Puff pastry	paper Baking tray + greaseproof paper	3 (4)	200	₫ <u>n</u>	15	Recipe tip: With sesame seeds, poppy seeds, icing.
Puff pastry twists	Baking tray + greaseproof paper	3 (4)	200	J _p	15	Recipe tip: Fill with cheese, ham, or nuts.
Small pastries	Baking tray + greaseproof paper	2 (3)	200	Sp.	15–20	Recipe tip: Serve with custard and/or fruit.
Waffle biscuits	Baking tray + greaseproof paper	2 (3)	140	J _P	8–10	Shape the waffle biscuits whilst they are still hot, e.g. into ice cream cones or small rolls for dessert.
Breadsticks	Baking tray + greaseproof paper	2 (3)	160	J.	30	Sprinkle with sea salt, rosemary, curry powder, sesame seeds or caraway seeds.
Cookies (20 g each)	Baking tray + greaseproof paper	2 (3)	175	Sp.	12–14	With chocolate, raisins, nuts or lemon.

* Preheat the appliance to the specified temperature. Turn the temperature down to the second specified temperature when placing the food in the oven.

Dish	Accessories	Level	Temperature in °C	Type of heating	Cooking time (mins)	Comments
Brownies	Baking tray	2 (3)	120	4	60	Cut into squares or rectangles once
	+					baked. The low temperature means that
	greaseproof	- (e A		the brownies will stay gooey in the middle.
	paper	2 (3)	180	S e	40–45	No need to preheat; do not open the appli- ance door.
Muffins	Muffin tray/	2 (3)	160	*	25–30	With chocolate, nuts or raisins.
	paper	2 (3)	160		25–30	_
	cases	2 (3)	160–165		25–30	-
Small cakes	Glass tray	2	150**	*	25–30	Preheat
(in accordance with	Baking tray	3	150**	*	28–32	Preheat
EN60350-1)	Glass tray	1				Applies to baking on two levels
(Appliance width: 60 cm)	Glass tray	3	160**		20–25	Preheat
Small cakes	Glass tray	3	150**	4	26-32	Preheat
(in accordance with	Baking tray	4	150**	4	30-32	Preheat
EN60350-1)	Glass tray	2				Applies to baking on two levels
(Appliance width: 76 cm)	Glass tray	4	160**		23–24	Preheat
Piped cookies	Baking tray	2	140**	*	35–40	Preheat
(in accordance with	Baking tray	3	140**	4	35-40	Preheat
EN60350-1)	Glass tray	1				Applies to baking on two levels
(Appliance width:	Baking tray	2	140**		26-30	Preheat
60 cm)						
Piped cookies	Baking tray	3	140**	*	30–35	Preheat
(in accordance with	Baking tray	4	140**	*	30-40	Preheat
EN60350-1)	Glass tray	2				Applies to baking on two levels
(Appliance width: 76 cm)	Baking tray	3	140**		30–35	Preheat
Bread, bread rolls						
Multigrain bread	Baking tray	2 (3)	200 / 170*	*	40–50	
	+	2 (3)	200 / 170*		40–50	-
	greaseproof	2 (3)	200 / 165*		45–50	-
Sourdough bread	paper Baking tray	2 (3)	200 / 180*		50-60	
Olive and tomato	Baking tray	2 (3)	200 / 170*		40-50	
bread		. ,				
Bread in a loaf tin	Loaf tin	2 (3)	175		40–45	
Baguette,	Baking tray	2 (3)	220		10–12	
pre-baked	+					
	greaseproof					
Ciabatta,	paper Baking tray	2 (3)	190		12–14	
pre-baked	+	2 (3)	190	*	12-14	-
	greaseproof paper	2 (0)			.2 . T	
Flatbread	Baking tray	2 (3)	200	4	15–20	The cooking time depends on the size and
	+	2 (3)	210		15–20	thickness of the flatbread.
	greaseproof paper					

* Preheat the appliance to the specified temperature. Turn the temperature down to the second specified temperature when placing the food in the oven.

Dish	Accessories	Level	Temperature in °C	Type of heating	Cooking time (mins)	Comments
Foccacia	Baking tray + greaseproof paper	2 (3)	210		15–20	Top with various ingredients, e.g. herbs, sea salt, olives, anchovies, onion, ham, tomatoes or cheese.
Garlic/herb baguette	Baking tray + greaseproof paper	2 (3)	200		8–10	
Strudel made from puff pastry	Baking tray + greaseproof paper	2 (3)	200	3°	20–25	Recipe tip: Fill with sheep's cheese and feta cheese.
Plaited loaf	Baking tray	2 (3)	165	*	20	
	+ greaseproof paper	2 (3)	170	S e	30–35	No need to preheat; do not open the appli- ance door.
Bread rolls,	Baking tray	2 (3)	210		8–10	
pre-baked	+ greaseproof paper	2 (3)	200	J _P	8–10	-
Bread rolls,	Baking tray	2 (3)	180	*	10–12	
frozen	+ greaseproof paper	2 (3)	200		10–12	-
Bread rolls, fresh (50 g each)	Baking tray + greaseproof paper	2 (3)	250 / 200*		15–20	
Baked items made from lye-dipped yeast dough, frozen	Baking tray + greaseproof paper	2 (3)	200	ş	10–12	
Croissants, frozen	Baking tray + greaseproof paper	2 (3)	170		15–25	o the second specified temperature when

placing the food in the oven.

Desserts

- Oven-cooked desserts are very easy to prepare you just have to put it in the oven. This preparation method is useful for relatively large quantities, for example if you have guests.
- Oven-cooked desserts are generally eaten warm, and are particularly enjoyable during the cooler months.

Dish	Accessories	Level	Temperature in °C	Heating function	Cooking time in min.	Comments
Apple crumble	Ovenproof dish	2 (3)	200	4	35 - 40	Apple bake with a crumble topping; equally delicious with berries or mirabelles.
		2 (3)	200		25 - 30	For soft apple varieties.
		2 (3)	200		25 - 30	For firm apple varieties.
Baked apple	Ovenproof dish	2 (3)	190 - 200	5	20 - 30	Recommendation: Use cooking apples, e.g. Boskop. These are particularly well suited for cooking and baking.
						Summer version: Stuff with ricotta cheese, lemon, honey, cardamom, vanilla and pine nuts.
Compote	Glass dish/	2 (3)	160 - 180	4	30 - 40	e.g. apricots or a variety of berries
	grill tray	2 (3)	200		30 - 40	Do not add any liquid; stir thoroughly sev- eral times. Refine with honey, fresh vanilla or cinnamon.
	Ovenproof dish	2 (3)	190	₫ _₽	30 - 35	French dessert: Traditionally made with cherries; equally delicious with mirabelles or berries.
		2 (3)	200	÷	55	No need to preheat; do not open appliance door.
Sweet bake	Ovenproof dish	2 (3)	160 - 180	4	30 - 40	e.g. semolina, quark or rice pudding
Bread and butter pudding, Kirschen- michel (German bread and butter pudding with sour cherries)	Ovenproof dish	2 (3)	150	un Un	50 - 55	e.g. with cherries or apricots
Topfenpalat- schinken (baked sweet pancakes with a quark filling)	Ovenproof dish	2 (3)	180 - 190	<u> </u>	8 - 10	Austrian speciality: Pancakes filled with quark and raisins, topped with cream and grilled.
Meringue	Baking tray + grease- proof paper	2 (3)	100	₫ <u>a</u>	150	When dividing up the mixture, make sure that the portions are spread as thinly as possible so that the mixture dries out well.

Preserving

- Cook food as soon as possible after purchase or after it has been harvested. Prolonged storage reduces the vitamin content and means that food is on the verge of fermenting.
- Only use fruit and vegetables that are in good condition.
- The oven is not suitable for preserving meat.
- Carefully check and clean the preserving jars, rubber sealing rings, clips and springs.
- Place the preserving jars in a heat-resistant vessel containing water. Make sure that they do not touch. The water level must reach at least three quarters of the way up to the top of the contents of the jars.
- Once the cooking time has elapsed, open the cooking compartment door. Do not remove the preserving jars from the cooking compartment until they have completely cooled down.
- Store the preserves in a cool, dark and dry place, e.g. in a pantry. Once the jars have been opened, consume the contents quickly and store in the refrigerator.

Dish	Accessories	Level	Temperature in °C	0	Cooking time in min.	Comments
Fruit	Wire rack	1 (2)	150 - 160		35 - 40	In sealed jars
Vegetables	Wire rack	1 (2)	190 - 200		60 - 120	In sealed jars

Disinfecting

- Before you begin preserving the food, the glasses should be disinfected in the oven to prevent the food from spoiling. This is the only way to ensure that preserves keep for a relatively long time and can be stored outside of the refrigerator.
- Disinfect the empty jars at 100 °C for at least 20 minutes in the "Hot air" (fan-oven) setting. The lids and rubber preserving seals for the jars can be disinfected at the same time in boiling water to avoid them drying out in the dry heat of the oven.

Dish	Accessories	Level	Temperature in °C	0	Cooking time in min.	Comments
Disinfecting	Wire rack	2 (3)	100	4	20 - 25	Preserving jars, baby bottles

Drying

- Drying is a method of preserving food in which up to 50% of the liquid contained in the food is removed by exposing it to dry heat. This also makes the flavour more intense.
- The thicker the food, the longer the drying process lasts. The quickest way to dry food – which is also the method that saves the most energy – is to cut it into slices.
- Place the prepared food onto a wire rack or baking tray covered with greaseproof paper. Turn the food from time to time during the drying process.
- The duration depends on the thickness of the food and on the natural level of moisture in the food, i.e. tomatoes take longer to dry out than mushrooms.
- If you want to dry food in the oven on two levels at the same time, use levels 1 and 3 (or 2 and 4).

Dish	Accessories	Level	Temperature in °C	Heating function	Cooking time in hours	Comments
Sliced mushrooms	Wire rack + greaseproof paper	2 (3)	50 - 60	₫ _₽	3 - 4	
Apple rings	Wire rack + greaseproof paper	2 (3)	70	d _a	5 - 8	
Quartered tomatoes	Wire rack + greaseproof paper	2 (3)	60 - 70	₫ <u>a</u>	7 - 8	Core the tomatoes to avoid an extended drying time.
Herbs	Wire rack + greaseproof paper	2 (3)	50 - 60	d _a	1½ - 2	e.g. chives, parsley and sage

Baking stone

- You will need a baking stone and heating element these are optional accessories.
- Whether you are baking crispy pizza or fresh bread, with the baking stone, you will achieve results that are comparable to, or even exceed, those that you would get from a massive stone oven because you are able to precisely control the baking temperature.
- Depending on the size, you can place several pizzas, bread rolls or other baked items on the baking stone at once.
- You can bake several pizzas in succession. This may increase the baking time per pizza by approx. one to three minutes.
- When dough is baked, it needs to be able to expand without the surface breaking apart. This can be achieved by pricking it several times with a fork or by making a cut with a knife.
- The temperatures and times specified in the cooking table are average values. In addition, always follow the manufacturer's instructions for pre-cooked and frozen products.

Meal	Accessory/ ies	Level	Tempera- ture in °C	Type of heating	Cooking time (mins)	Comments
Bread rolls, fresh (50 g each)	Baking stone	1	250 / 200*	10100	15 - 20	
Flatbread	Baking stone	1	210	10100	15	The cooking time depends on the size and thickness of the flatbread
Foccacia	Baking stone	1	210		15	Top with various ingredients, e.g. herbs, sea salt, olives, anchovies, onion, ham, tomatoes or cheese.
Multigrain bread	Baking stone	1	175	10100	45	
Sourdough bread	Baking stone	1	250 / 200*	10100	50 - 60	
Olive and tomato bread	Baking stone	1	175	0000	45	
Pizza, fresh	Baking stone	1	275	ww	5 - 8	The cooking time varies depending on the type and thickness of the dough and topping.
Pizza, frozen	Baking stone	1	230	0000	8 - 10	The cooking time varies depending on the thickness of the dough. Follow the manufacturer's instructions.
Tarte flambée, fresh	Baking stone	1	300		3 - 4	Recipe tip: Traditional or with goat's cheese, Parma ham, figs and spring onions.
Tarte flambée, frozen	Baking stone	1	250		4 - 5	n when placing the food in the oven.

Acrylamide in foodstuffs

Which foods are affected?

Acrylamide is mainly produced in grain and potato products that are heated to high temperatures, such as crisps, chips, toast, bread rolls, bread, fine baked goods (biscuits, gingerbread, cookies).

Tips for keeping acrylamide to a minimum when preparing food	
General	Keep cooking times as short as possible. Cook food until it is golden brown, but not too dark. Large, thick pieces of food con- tain less acrylamide.
Baking	With hot air at max. 180 °C.
Biscuits	Egg or egg yolk reduces the production of acrylamide. Spread out a single layer evenly on the baking tray.
Oven	Cook at least 400 g at once on a baking
Chips	tray so that the chips do not dry out.

BSH Hausgeräte GmbH Carl-Wery-Straße 34 81739 München, GERMANY www.gaggenau.com

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom



