

CE291...

Hob

CE291...




Table of contents

1	Safety	3
2	Preventing material damage	4
3	Environmental protection and saving energy	5
4	Familiarising yourself with your appliance	6
5	Basic operation	7
6	PowerBoost function	8
7	Frying sensor function	8
8	Childproof lock	10
9	Time-setting options	10
10	Safety switch-off	11
11	Wipe protection	11
12	Basic settings	12
13	Cleaning and servicing	13
14	Troubleshooting	13
15	Disposal	14
16	Customer Service	15



1 Safety

Observe the following safety instructions.

1.1 General information

- Read this instruction manual carefully.
- Keep the instructions, the appliance pass and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under the warranty.

Only use this appliance:

- To prepare meals and drinks.
- Under supervision. Never leave the appliance unattended when cooking for short periods.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 2000 m above sea level.

Do not use the appliance:

- With an external timer or a separate remote control. This does not apply if operation with appliances included in EN 50615 is switched off.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Children must not play with the appliance. Children must not perform cleaning or user maintenance unless they are at least 15 years old and are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

1.4 Safe use

WARNING – Risk of fire!

Leaving fat or oil cooking on an unattended hob can be dangerous and may lead to fires.

- ▶ Never leave hot oil or fat unattended.
- ▶ Never attempt to extinguish a fire using water; instead, switch off the appliance and then cover with a lid or a fire blanket.

The cooking surface becomes very hot.

- ▶ Never place flammable objects on the cooking surface or in its immediate vicinity.
- ▶ Never place objects on the cooking surface.

The appliance will become hot.

- ▶ Do not keep combustible objects or aerosol cans in drawers directly underneath the hob.

Hob covers can cause accidents, for example due to overheating, catching fire or materials shattering.

- ▶ Do not use hob covers.

Food may catch fire.

- ▶ The cooking process must be monitored. A short process must be monitored continuously.

⚠ WARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use, particularly the hob surround, if fitted.

- ▶ Caution should be exercised here in order to avoid touching heating elements.
- ▶ Young children under 8 years of age must be kept away from the appliance.

Hob protective grilles may cause accidents.

- ▶ Never use hob protective grilles.

The appliance becomes hot during operation.

- ▶ Allow the appliance to cool down before cleaning.

⚠ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- ▶ Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced with a special connection cable, which is available from the manufacturer or his Customer Service.

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ▶ If the surface is cracked, you must switch off the appliance in order to prevent a possible electrical shock. To do this, switch off

the appliance via the fuse in the fuse box rather than at the main switch.

- ▶ Call customer services. → *Page 15*

An ingress of moisture can cause an electric shock.

- ▶ Do not use steam- or high-pressure cleaners to clean the appliance.

The insulation on cables of electrical appliances may melt if it touches hot parts of the appliance.

- ▶ Never bring electrical appliance cables into contact with hot parts of the appliance.

⚠ WARNING – Risk of injury!

Saucepans may suddenly jump due to liquid between the saucepan base and the hotplate.

- ▶ Always keep hotplates and saucepan bases dry.

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ▶ Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

Children may breathe in or swallow small parts, causing them to suffocate.

- ▶ Keep small parts away from children.
- ▶ Do not let children play with small parts.

2 Preventing material damage

ATTENTION!

Rough pot and pan bases will scratch the ceramic.

- ▶ Check your cookware.

Boiling pans dry may damage cookware or the appliance.

- ▶ Never place empty pans on a heated hotplate or allow to boil dry.

Incorrectly positioned cookware can cause the appliance to overheat.

- ▶ Never place hot pots or pans on the controls or the hob surround.

Damage can occur if hard or pointed objects fall onto the hob.

- ▶ Do not let hard or pointed objects fall onto the hob.

Non heat-resistant materials will melt on heated hotplates.

- ▶ Do not use oven protective foil.
- ▶ Do not use aluminium foil or plastic containers.

2.1 Overview of the most common damage

Here you can find the most common types of damage and tips on how to avoid them.

Damage	Cause	Measure
Stains	Food boiling over	Remove boiled-over food immediately with a glass scraper.
Stains	Unsuitable cleaning products	Only use cleaning products that are suitable for glass ceramic.
Scratches	Salt, sugar or sand	Do not use the hob as a work surface or storage space.
Scratches	Rough pot or pan bases	Check your cookware.
Discolouration	Unsuitable cleaning products	Only use cleaning products that are suitable for glass ceramic.
Discolouration	Pan abrasion, e.g. aluminium	Lift pots and pans to move on the hob.

Damage	Cause	Measure
Blisters	Sugar or food with a high sugar content	Remove boiled-over food immediately with a glass scraper.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

- Sort the individual components by type and dispose of them separately.

3.2 Saving energy

If you follow these instructions, your appliance will use less energy.

Select the cooking zone to match the size of your pan. Centre the cookware on the hob.

Use cookware whose base diameter is the same diameter as the hotplate.

Tip: Cookware manufacturers often give the upper diameter of the saucepan. It is often larger than the base diameter.

- Unsuitable cookware or incompletely covered cooking zones consume a lot of energy.

Cover saucepans with suitable lids.

- Cooking without a lid consumes far more energy.

Lift lids as infrequently as possible.

- When you lift a lid, a lot of energy escapes.

Using a glass lid

- You can see into the pan through a glass lid without having to lift it.

Use pots and pans with flat bases.

- Uneven bases increase energy consumption.

Use cookware suited to the quantity of food.

- Large items of cookware containing little food need more energy to heat up.

Cook with little water.

- The more water contained in cookware, the more energy is required to heat it up.

Turn down to a lower heat setting early on. Use a suitable ongoing cooking setting to continue cooking.

- If you continue cooking with an ongoing cooking setting that is too high, you'll waste energy

Take advantage of the hob's residual heat. With longer cooking times switch off the hotplate 5-10 minutes before the end of cooking.


- Unused residual heat increases energy consumption.

4 Familiarising yourself with your appliance

The instruction manual is the same for various different hobs. You can find the hob dimensions in the overview of models. → Page 2

4.1 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



4.2 Indicators/symbols

The displays show selected values and functions.

Display	Name
1 - 9	Heat settings
H / h	Residual heat
b	PowerBoost function
8 8	Timer

4.3 Touch fields

Touch fields are touch-sensitive surfaces. To select a function, touch the relevant field.

Touch field	Name
①	Main switch
☞	Wipe protection/Child-proof lock
+	Automatic zone control
»»	PowerBoost function
■	Hotplate selection
1 2 3 4	Settings range
🌊	Sensor frying system
🕒	Timer

Notes

- Always keep the control panel dry. Moisture impairs the function.
- Do not pull pans close to the displays and touch fields. The electronics may overheat.

4.4 Hotplates

You can find an overview of the different activations of the hotplates here.

If you operate the activations, the relevant displays light up.

Hot-plate	Name	Activating and deactivating
○	Single-circuit cooking zone	
◎	Dual-circuit hotplate	Select the hotplate. Touch +.
◎	Tri-circuit hotplate	Select the hotplate. <ul style="list-style-type: none"> Touch +. Second filament circuit is activated. Touch + again. Third filament circuit is activated.
0	Roaster hotplate	Select one of the two roaster hotplates. <ul style="list-style-type: none"> Touch +. Second hotplate and roaster are activated.

Notes

- Dark areas in the glow pattern of the hotplate are part of the technical design. They do not affect the functionality of the hotplate.
- The hotplate regulates the temperature by switching the heat on and off. The heat may also switch on and off when at the highest setting.

- With multi-circuit hotplates, the heating of the hotplate and the activated areas may switch on or off at different times.

Reasons:


- Easily damaged components are protected against overheating.
- The appliance is protected against electrical overload.
- This achieves a better cooking result.

5 Basic operation

5.1 Switching the hob on or off

The main switch is used to switch the hob on and off. If you switch the appliance back on again within 4 seconds after switching off, the hob will start up with the previously stored settings.

5.2 Switching on the hob

- ▶ Touch ①.
- ✓ The indicator lamp above ① lights up.
- ✓ The  displays light up.
- ✓ The hob is ready for use.

5.3 Switching off the hob

The hob will switch off automatically when all hotplates have been switched off for a while (10-60 seconds).

- ▶ Touch ①.
- ✓ The indicator lamp above ① goes out.
- ✓ The displays go out.
- ✓ All hotplates are switched off.
- ✓ The residual heat indicator remains on until the hotplates have cooled down sufficiently.




5.4 Setting the hotplates

To set a hotplate, it has to be selected. Select the required heat setting on the control panel.

Heat setting	
1	Lowest setting
9	Highest setting
.	Every heat setting has an intermediate setting, e.g. 4. .



5.5 Selecting heat settings

Requirement: The hob is switched on.


1. Select the hotplate with .
- ✓  lights up in the heat setting indicator.  lights up under the heat setting indicator.

4.5 Residual heat indicator

The hob has a two-stage residual heat indicator for each hotplate. Do not touch the hotplate while the residual heat indicator is lit up.


Display	Meaning
	The hotplate is so hot that you can keep small dishes warm or melt cooking chocolate.
	The hotplate is hot.

2. Select a heat setting on the control panel.




- ✓ The hotplate is switched on.

5.6 Changing heat settings

1. Select the hotplate with .
2. Select a heat setting on the control panel.

5.7 Switching off the hotplate

If you have switched off a hotplate, the residual heat indicator appears after approx. 10 seconds.

1. Select the hotplate with .
2. Select 0 on the control panel.

5.8 Recommended cooking settings

You can find an overview of different foods with appropriate heat settings here.

The cooking time will vary depending on the type, weight, thickness and quality of the food. The ongoing cooking setting depends on the cookware used.

Heat setting	Cooking method	Examples
9	Bringing to the boil	Water
9	Searing	Meat
9	Heating	Fat, liquids
9	Bringing to the boil	Soups, sauces
9-8.	Blanching	Vegetables
8-6	Frying	Meat, potatoes
6-5	Frying	Fish.
7-6	Baking	Flour-based foods, egg-based foods

Heat setting	Cooking method	Examples
7-6	Simmering in an uncovered dish	Dough-based foods, liquids
6-5	Browning	Flour, onions
6-5	Toasting	Almonds, breadcrumbs
6-5	Rendering	Bacon
6-5	Reducing	Stock, sauces
5.-4.	Poaching in an uncovered dish	Dumplings, soup vegetables, soup meat, poached eggs
4-3	Poaching in an uncovered dish	Boiled sausages
5-4	Steaming	Vegetables, potatoes, fish

Heat setting	Cooking method	Examples
5-4	Stewing	Vegetables, fruit, fish
5-4	Stewing	Beef olives, joints, vegetables
3.-2.	Stewing	Goulash
4.-3.	Simmering with the lid on	Soups, sauces
3.-2.	Defrosting	Frozen food
3-2	Soaking	Rice, pulses
3-2	Thickening	Egg dishes
2-1	Heating/keeping warm	Soups, stews, vegetables in sauce
2-1	Melting	Butter, chocolate

6 PowerBoost function

PowerBoost lets you heat up large volumes of water even faster than on heat setting 9. The PowerBoost function is only available on hotplates marked >>.

6.1 Switching on PowerBoost

WARNING – Risk of fire!

Oil and fat heat up quickly with the PowerBoost function. Oil and fat ignite quickly if overheated.

- ▶ When cooking, never leave the hob unattended.

Requirement: With dual-circuit hotplates, the second filament circuit has to be activated for use with the PowerBoost function.

1. Select the cooking zone.
2. Touch >> on the control panel.
 - ✓ The **b** indicator lights up.

6.2 Switching off PowerBoost

If you do not switch off the PowerBoost function, it will switch off automatically after a certain period of time. The hotplate switches back to heat setting 9.

1. Select the hotplate.
2. Select any ongoing cooking setting.
 - ✓ The **b** display goes out.

7 Frying sensor function

The tri-circuit hotplate has a sensor frying function. The sensor frying system monitors the temperature in the pan so it is regulated automatically.

The benefit to you when frying:

- The regulated heating process saves energy.
- Oil and fat will not overheat.

Note: The second filament circuit in the tri-circuit hotplate is activated automatically when setting sensor frying.

7.1 Pans for the sensor frying system

Use a suitable pan when cooking with the sensor frying system.

System pans as optional accessories

You can buy a pan that is perfectly suited to cooking with the sensor frying system from your specialist electrical retailer or the online shop: GP900003.

Conventional pan

The sensor frying system will also function with a conventional pan.

- Test pans on a low frying setting. If the frying setting is too high, the pan may overheat.

- Adjust the frying setting if necessary.

7.2 Frying settings

Select an appropriate frying setting to cook your food.

Frying setting	Temperature	Use
max	max	<ul style="list-style-type: none"> ■ Steak, rare (saignant) ■ Potato pancakes ■ Roast potatoes
med	medium – high	<ul style="list-style-type: none"> ■ Breaded frozen products ■ Thin foods, e.g. escalopes, meat in strips or vegetables
low	low - medium	<ul style="list-style-type: none"> ■ Fish ■ Thick foods, e.g. rissoles or sausages
min	low	<ul style="list-style-type: none"> ■ Omelettes ■ Fried in butter, olive oil or margarine.


7.3 Setting the sensor frying system

Once you have selected an appropriate frying setting from the recommended settings, you can adjust the sensor frying system.

Requirements

- The empty pan is positioned on the hotplate.
- The hob is switched on.
- The hotplate is selected.


1. Touch .



- ✓ *R* lights up on the hotplate display.
 - ✓ The frying settings appear in the display menu.
2. Select the required frying setting on the control panel.

min	Heat setting 2
low	Heat setting 4
med	Heat setting 6
max	Heat setting 8

- ✓ The sensor frying system is activated.



- ✓ The large dual-circuit hotplate is switched on automatically.
 - ✓ • lights up until the frying temperature is reached. A signal then sounds. • goes out.
3. Add the fat to the pan.
4. Add the food to the pan.
5. Turn as you would normally to prevent burning.

7.4 Switching off the sensor frying system

- Touch .

7.5 Recommended setting for frying with sensor frying system

This is where you can find recommendations regarding which frying setting is best used for what food. The frying time depends on the type, weight, thickness and quality of the food.

Cooking tips

- The frying settings given here are for cooking with the system pan. The frying settings may vary if you use different pans.
- First heat the empty pan. Add the fat and the food to the pan when the signal sounds.

Meat

Food	Frying setting	Total frying time in minutes after the signal
Veal escalope, plain or breaded, 1.5 cm thick	med	6-10
Fillet, pork, beef or veal, 2.5 cm thick	med	6-10
Cutlet, pork or lamb, 2 cm thick	low	10-17
Beef steak, rare, 3 cm thick	max	6-8
Beef steak, medium or well done, 3 cm thick	med	8-12
Saddle of lamb, medium, 1.5-2.5 cm thick	low	10-15
Chicken breast, 2 cm thick	low	10-20
Bratwurst sausage, boiled or raw, diameter 1-3 cm	low	8-20
Hamburgers, rissoles, 1-3 cm thick	low	6-30
Strips of meat	med	7-12
Minced meat	med	6-10
Bacon rashers	min	5-8

Fish.

Whole fish	low	15-25
Fish fillet, breaded or plain	low/ med	10-20
Salmon steak, 2.5 cm thick	low	8-12
Tuna steak, well done, 2.5 cm thick	low	8-12
Scampi, prawns	med	4-8
Scallops	med	5-8

Egg dishes

Pancakes	med	frying one after the other
Omelettes	min	frying one after the other
Fried eggs	min/ med	2-6

Scrambled eggs	min	2-4
French toast	low	frying one after the other

Potatoes

Fried potatoes (made from un-peeled boiled potatoes)	max	6-12
Fried potatoes from raw potatoes	low	15-25
Potato pancakes	max	frying one after the other
Rösti (Swiss potato fritter)	min	30-40
Glazed potatoes	med	10-15

Vegetables

Garlic, onions	min	2-10
----------------	-----	------

Courgettes, aubergines	low	4-12
Peppers, green asparagus, carrots	low	4-15
Mushrooms	med	10-15
Glazed vegetables	med	6-10

Frozen products

Fish fillet, plain or breaded, 0.5-1 cm thick	low	10-20
Stir-fries, stir-fried vegetables	min	8-15
Spring rolls, 2.5-3 cm thick	low	10-30

Other



Rice, pasta	max	8-15
Croûtons	low	6-10
Toasting almonds, nuts or pine kernels	min	3-7

8 Childproof lock


You can use the childproof lock to prevent children from switching on the hob.

8.1 Activating the childproof lock

Requirement: The hob is switched off.

- ▶ Press and hold  for approx. 4 seconds.
- ✓  lights up for approx. 10 seconds.
- ✓ The hob is locked.

8.2 Deactivating the childproof lock

- ▶ Press and hold  for approx. 4 seconds.
- ✓ The lock is now released.

8.3 Automatic childproof lock

This function automatically activates the childproof lock when you switch off the hob.

The automatic childproof lock can be activated in the basic settings. → [Page 12](#)

9 Time-setting options

Your appliance has different time-setting options which can be used to set a cooking time or a kitchen timer.

9.1 Cooking time


Enter a cooking time for the relevant hotplate. When the cooking time has elapsed, the hotplate switches off automatically.



You can set a cooking time of up to 99 minutes. When you fry with the sensor frying system, the cooking time set will only begin when the temperature for the selected area is reached.

Setting the cooking time


Requirement: The hotplate is selected and set.

1. Touch .



- ✓ The  indicator for the hotplate lights up.  lights up on the timer display.

2. Within the next 10 seconds set the required cooking time on the control panel.



- ✓ The cooking time counts down. If you have set a cooking time for more than one hotplate, the cooking time of the hotplate selected is displayed.
- ✓ When the cooking time has elapsed, the hotplate switches off. A signal sounds and **00** flashes on the display for 10 seconds. The **I→I** display lights up brightly.

Changing or cancelling the cooking time

1. Select the hotplate.
 2. Touch **⏸**.
- ✓ The **I→I** display lights up brightly.
3. On the control panel change the cooking time or set it to **00**.

Switching off the continuous signal

You can switch the signal off manually.

- ▶ Touch any symbol.
- ✓ The displays will go out and the audible signal will stop.

Automatic timer

You can use this function to preselect a cooking time for all hotplates. Each time a hotplate is switched on, the preselected cooking time counts down. When the cooking time has elapsed, the hotplate switches off automatically.

Switch on the automatic timer in the basic settings.
→ Page 12

Tip: The automatic timer is valid for all hotplates. You can reduce or delete the cooking time for individual hotplates. → Page 10

9.2 Kitchen timer

You can set a time of up to 99 minutes after which a signal will then sound. The kitchen timer runs independently of all other settings.

Setting the kitchen timer

1. Switch on the kitchen timer.

There are 2 different ways of switching the kitchen timer on.

If a hotplate has been selected.	Touch ⏸ twice within 10 seconds.
If a hotplate has not been selected.	Touch ⏸ .

- ✓ The **⏸** indicator lights up.
2. Within the next 10 seconds set the required time on the control panel.
- ✓ The time counts down.
 - ✓ When the time has elapsed, a signal sounds. **00** lights up on the timer display. The **⏸** indicator for the kitchen timer lights up brightly. It switches off after 10 seconds.

Displaying the time

- ▶ Select the kitchen timer with **⏸**.
- ✓ The time is displayed for 10 seconds.

Setting the correct time

1. Select the kitchen timer with **⏸**.
2. Set the required time on the control panel.

10 Safety switch-off

If you do not change the settings of a hotplate for a long time, safety switch-off will be activated. When the hotplate switches off depends on the heat setting selected (1 to 10 hours). The hotplate stops heating. **FB** and the residual heat indicator **H/h** flash alternately on the hotplate display.

10.1 Overriding safety switch-off

1. Touch any control.
- ✓ The display goes out.
2. Reset.

11 Wipe protection

Wiping over the control panel while the hob is switched on may alter settings. Your hob has a wipe protection function to prevent this. The main switch is excluded from the wipe protection function. You can switch the hob off at any time.

11.1 Activating wipe protection

- ▶ Touch **⏸**.
- ✓ A signal will sound.
- ✓ The indicator lamp above **⏸** lights up.
- ✓ The control panel is locked for 30 seconds.

12 Basic settings

You can configure the appliance to meet your needs.

12.1 Overview of the basic settings

You can find an overview of the basic settings and the default factory settings here.

Dis-play	Selection
c /	Automatic childproof lock □ – Switched off ¹ / – Switched on 2 – Manual and automatic childproof lock are switched off.
c 2	Signal tone □ – Confirmation signal and operating error signal are switched off. The main switch signal remains switched on. / – Only the operating error signal is switched on. 2 – Only the confirmation signal is switched on. 3 – Confirmation signal and operating error signal are switched on. ¹
c 5	Automatic timer □□ – Switched off. ¹ 1-99 – Cooking time after which the hotplates switch off.
c 6	Duration of the timer end signal / – 10 seconds. ¹ 2 – 30 seconds. 3 – 1 minute.
c 7	Activation of the heating elements □ – Switched off / – Switched on 2 – The last setting before switching off the hotplate. ¹
c 9	Time for selecting hotplates □ – Unlimited: The last hotplate selected can always be adjusted without having to select it again. ¹ / – You can adjust the last hotplate selected within 10 seconds after selecting it. After this time you have to select the hotplate again before adjusting it.

¹ Factory setting


Dis-play	Selection
c □	Resetting to the factory settings □ – Switched off. ¹ / – Switched on.

¹ Factory setting


12.2 Changing basic settings

Requirement: The hob is switched off.

1. Switch on the hob.
2. Within the next 10 seconds press and hold ⌚ for approx. 4 seconds.



- ✓ c and / flash alternately on the left-hand display.
 - ✓ □ lights up on the right-hand display.
3. Touch ⌚ repeatedly until the required indicator appears on the left-hand display.
 4. Set the required value on the control panel.



5. Press and hold ⌚ for 4 seconds.

✓ The setting is activated.

Tip: To exit the basic settings, switch off the hob using ⌚. Switch the hob on again and reset.

13 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

13.1 Cleaning products

You can obtain suitable cleaning products and glass scrapers from customer service, the online shop or a retailer.

ATTENTION!

Unsuitable cleaning products may damage the surfaces of the appliance.

- ▶ Never use unsuitable cleaning products.

Unsuitable cleaning products

- Undiluted detergent
- Detergent intended for dishwashers
- Abrasive cleaners
- Aggressive cleaning products such as oven spray or stain remover
- Abrasive sponges
- High-pressure or steam jet cleaners

13.2 Cleaning the glass ceramic

Clean the hob after every use to stop cooking residues from getting burnt on.

Note: Note the information on unsuitable cleaning products. → *Page 13*

Requirement: The hob has cooled down.

1. Remove heavy dirt using a glass scraper.
2. Clean the hob with a cleaning product for glass ceramic.

Follow the cleaning instructions on the product packaging.

Tip: You can achieve good cleaning results if you use a special sponge for glass ceramic.

13.3 Cleaning the hob surround

Clean the hob frame after use if dirty or stained.

Notes

- Note the information on unsuitable cleaning products. → *Page 13*
 - Do not use the glass scraper.
1. Clean the hob frame with hot soapy water and a soft cloth.
Wash new sponge cloths thoroughly before use.
 2. Dry with a soft cloth.

14 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

WARNING – Risk of injury!

Improper repairs are dangerous.

- ▶ Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ If the appliance is defective, call Customer Service.

WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- ▶ Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.

- ▶ If the power cord of this appliance is damaged, it must be replaced with a special connection cable, which is available from the manufacturer or his Customer Service.

WARNING – Risk of burns!

The hotplate heats up but the display does not work.

- ▶ Switch off the fuse in the fuse box.
- ▶ Call the customer service.

WARNING – Risk of fire!

The hob switches off automatically and can no longer be operated. It may switch on unintentionally at a later point.

- ▶ Switch off the fuse in the fuse box.
- ▶ Call the customer service.

14.1 Information on display panel

Fault	Cause and troubleshooting
None	There has been a power cut. <ol style="list-style-type: none"> 1. Check the household fuse for the appliance. 2. Check whether there has been a power failure by trying other electrical appliances.
All displays flash	The control panel is wet or objects are lying on it. <ul style="list-style-type: none"> ▶ Dry the control panel or remove the object.

Fault	Cause and troubleshooting
F2	Several hotplates have been used over a prolonged period at high power settings. The hotplate has been switched off to protect the electronics. <ol style="list-style-type: none"> 1. Wait a while. 2. Touch any touch field. ✓ When the message no longer appears, the electronics have cooled down sufficiently. You can continue to cook.
F4	Despite being switched off by F2 , the electronics have become hot again. All hotplates have therefore been switched off. <ol style="list-style-type: none"> 1. Wait a while. 2. Touch any touch field. ✓ When the message no longer appears, the electronics have cooled down sufficiently. You can continue to cook.
F5 and the heat setting flash alternately. A signal sounds.	Hot pot near the control panel. There is a risk that the electronics will overheat. <ul style="list-style-type: none"> ► Remove the pan. ✓ The display goes out shortly afterwards.
F5 and audible signal	Hot pot near the control panel. The hotplate has been switched off to protect the electronics. <ol style="list-style-type: none"> 1. Remove the pot. 2. Wait a while. 3. Touch any touch field. ✓ When the message no longer appears, the electronics have cooled down sufficiently. You can continue to cook.
F8	The hotplate was on for too long and has switched off automatically. You can switch the hotplate back on again immediately.
dE and hotplates do not heat up	Demo mode is activated. <ol style="list-style-type: none"> 1. Disconnect the appliance from the power supply for 30 seconds by briefly switching off the circuit breaker in the fuse box. 2. Touch any touch field within the next three minutes.
A message with "E" appears on the display, e.g. E0111.	The electronics have detected a fault. <ol style="list-style-type: none"> 1. Switch the appliance off and on again. ✓ If the fault was a one-off, the message disappears. <ol style="list-style-type: none"> 2. If the message appears again, call the after-sales service. Please specify the exact error message when calling. → "Customer Service", Page 15

15 Disposal

Find out here how to dispose of old appliances correctly.

15.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

- Dispose of the appliance in an environmentally friendly manner.

Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

16 Customer Service

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service.

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our after-sales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

16.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate.

The rating plate can be found:

- on the appliance certificate.
- on the lower section of the hob.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

Gaggenau Hausgeräte GmbH

Carl-Wery-Straße 34

81739 München

GERMANY

www.gaggenau.com

Valid within Great Britain:

Imported to Great Britain by

BSH Home Appliances Ltd.

Grand Union House

Old Wolverton Road

Wolverton, Milton Keynes

MK12 5PT

United Kingdom

GAGGENAU



9001591629 en (010309)