Gaggenau

User manual and installation instructions

WT260110

Tumble dryer

Futher information and explanations are available online:



Table of contents

1 Safety	. 4
1.1 General information	. 4
1.2 Intended use	
1.3 Restriction on user group	. 4
1.4 Safe installation	
1.5 Safe use	. 7
1.6 Safe cleaning and maintenance	. 9
2 Preventing material damage	11
3 Environmental protection and saving energy	11
3.1 Disposing of packaging	11
3.2 Saving energy	11
3.3 Energy saving mode	12
4 Installation and connection	12
4.1 Unpacking the appliance	12
4.2 Scope of delivery	12
4.3 Requirements for the installation location	13
4.4 Water drain hose	14
4.5 Aligning the appliance	16
4.6 Reversing the door	16
4.7 Connecting the appliance to	
the electricity supply	18
5 Familiarising yourself with	00
your appliance5.1 Appliance	20 20
5.2 Wool basket	21
5.3 Control panel	21
5.4 Operating logic	22
6 Display	23
7 Buttons	26

8 Dryness level	29
8.1 Changing the dryness level 8.2 Adjusting the dryness level	29 29
9 Programmes	30
9.1 Automatic programmes	30
9.2 Timed programmes	32
10 Accessories	34
11 Laundry	34
11.1 Preparing the laundry	34
12 Basic operation	35
12.1 Switching on the appliance	35
12.2 Setting a programme	35
12.3 Adjusting the programme	25
settings12.4 Saving the programme set-	35
tings	35
12.5 Loading laundry	35
12.6 Starting the programme	35
12.7 Adding laundry	36
12.8 Cancelling the programme 12.9 Unloading the laundry	36 36
12.10 Switching off the appli-	00
ance	36
12.11 Filter system on the base	00
unit 12.12 Condensation container	36 38
13 Childproof lock	39
13.1 Activating the childproof	39
lock	39
13.2 Deactivating the childproof	00
lock	39

14 Crease-removal function14.1 Starting a programme with the crease-removal function	39	19.3 Water tank filter	
14.2 Filling the water tank		ter	52
15 Wool basket 15.1 Inserting the wool basket		20 Troubleshooting	54
15.2 Starting a programme with the wool basket15.3 Examples of how to use the wool basket	41	21 Transportation, storage and disposal	60
16 Home Connect	42	21.2 Disposing of old appliance	
16.1 Setting up the Home Connect app16.2 Setting up Home Connect		22 Customer Service	
16.3 Activating Wi-Fi on the ap-		23 Consumption values	62
pliance		24 Technical data	63
appliance 16.5 Resetting the appliance	44	25 Declaration of Conformity	64
network settings			
commendation	45		
17 Basic settings	46		
17.1 Overview of the basic settings	46		
17.2 Changing the basic set-			
tings			
18 Appliance care 18.1 Preparing for appliance			
care	47		
care programme	47		
18.3 Running the basic appliance care programme	48		
18.4 Running the intensive appliance care programme	48		
19 Cleaning and servicing	50		
19.1 Tips on cleaning and care	50 50		

en



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- For drying and freshening up fabrics that are washed with water and suitable for dryers.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Incorrect installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ► Never connect the appliance to a circuit that is regularly switched on and off by the energy supplier.
- ► When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ► When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.

en Safety

▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

⚠ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- ► Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material.

△ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ► Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

⚠ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

- ► Do not touch the sharp edges on the appliance.
- Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ► Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer services. → Page 61

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- ► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

△ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ► Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

↑ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

⚠ WARNING – Risk of explosion!

If there is coal dust or flour in the air around the appliance, this may cause an explosion.

► Keep the area around the appliance clean during operation.

⚠ WARNING – Risk of poisoning!

Condensation water from this appliance is not suitable for drinking and may be contaminated with fluff.

Do not drink or reuse the condensation water from the appliance.

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of fire!

The refrigerant R290 in this appliance is environmentally friendly yet combustible and may ignite if it comes into contact with open flames or ignition sources.

► Keep naked flames and ignition sources away from the appli-



△ WARNING – Risk of explosion!

Highly flammable objects such as lighters or matches may ignite during the drying process.

► Remove all highly flammable objects from any pockets in your laundry before the drying process.

Unwashed laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when drying is in progress.

- ► Do not place laundry in this appliance to be dried if the laundry has not been washed first.
- ► Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- ▶ Do not use the appliance if industrial chemicals have been used to clean the laundry beforehand.

If drying is interrupted early, the laundry is not cooled sufficiently and may ignite.

- ▶ Do not interrupt the drying programme early.
- ► If drying is interrupted early, remove the laundry immediately and spread it out.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

- ▶ Do not stand on or climb onto the appliance.
- The appliance may tip over if you sit on or lean against the open door.
- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

Wait for the drum to come to a complete stop before reaching inside.

1.6 Safe cleaning and maintenance

★ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

► Do not use cleaning agents that contain solvents.

2 Preventing material damage

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 30 The function of the appliance may be impaired if the appliance overheats.
- Keep the ventilation opening on the appliance clear during operation.
- Make sure that the area is adequately ventilated.

Light objects such as hair and fluff may be sucked in from the ventilation opening on the appliance during operation and impair the function of the appliance.

- ► Keep the area around the appliance clean during operation.
- Keep light objects away from the appliance.

Foam and foam rubber may deform or melt during the drying process.

► Do not dry laundry that contains foam or foam rubber.

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.

- Clean the appliance with nothing but water and a soft, damp cloth.
- ► Remove all detergent residue. spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Operate the appliance in a well-ventilated room and keep the ventilation opening on the appliance clear.

✓ If air exchange is impeded, this extends the programme duration and increases energy consumption.

Spin the laundry in the washing machine before drying.

 Damper laundry extends the programme duration and increases energy consumption.

Observe the programme's maximum load capacity.

- → "Programmes", Page 30
- ✓ If the maximum load is exceeded, this extends the programme duration and increases energy consumption.

Dry the filters in the filter system of the base unit \rightarrow *Page 36* thoroughly after cleaning.

 If the filters are damp, this extends the programme duration and increases energy consumption.

Deactivate Wi-Fi on the appliance if it is not being used.

- → "Deactivating Wi-Fi on the appliance". Page 44.
- If the Wi-Fi is activated, this increases energy consumption.

3.3 Energy saving mode

appliance, it switches off.

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. All displays go out and DM flashes. Energy-saving mode ends when you use the appliance again. If you do not continue operating the

Note: If Wi-Fi is activated, the appliance will not switch itself off automatically.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

 Remove these objects, along with all supplied accessories, from the drum before starting the appliance.

- Remove any packaging and protective covers completely from the appliance.
 - → "Disposing of packaging", Page 11
- 2. Check the appliance for visible damage.
- 3. Open the door.
- Remove any accessories from the drum.
- 5. Close the door.

4.2 Scope of delivery

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- Do not operate the appliance with incomplete or defective accessories.
- Replace the accessories in question before operating the appliance.
 - → "Accessories", Page 34

Included with the appliance	Description
	Tumble dryer
	Accompanying documents

Included with **Description** the appliance Water drain hose with connection adapter, fixing material and elbow. → "Water drain hose", Page 14 Water jug → "Filling the water tank". Page 40 Wool basket with insert → "Wool basket". Page 41

4.3 Requirements for the installation location

ATTENTION!

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- ► Tilt the appliance carefully.
- ► Transport the appliance in an upright position.

If residual water in the appliance freezes, this may cause damage to the appliance.


▶ Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is operated immediately after transportation, the refrigerant contained in the appliance may result in damage to the appliance.

 Immediately after transporting the appliance, leave it to rest for two hours before putting it into operation.

Installation loca- Requirements tion

On the floor



Place the appliance on a clean, level and firm surface. Align the appliance → Page 16.

In a washer-dryer stack




Only use the original connection set from the dryer manufacturer when setting up this appliance in a washer-dryer stack.

- Connection kit with pull-out worktop
 - → Page 34

This appliance must only be stacked on a washing machine from the same manufacturer. The depth and width of this appliance must correspond with the dimensions of the washing machine. Do not place the washer-drver stack on a plat-

Against a wall



Do not trap the hoses and power cord between the wall and the appliance.

form.

4.4 Water drain hose

Condensation forms during drying, which your appliance uses for automatic cleaning. Use the water drain hose to drain away excess condensation directly into the waste water system.

Notes

- Operate this appliance using the water drain hose provided. If you connect the water drain hose → Page 14, you do not have to regularly empty the condensation container → Page 38.
- You can order this optional → "Accessories", Page 34 from our customer service.

Connecting the water drain hose

If you do not want to regularly empty the appliance's condensation container, connect the water outlet hose.

ATTENTION!


When operating the appliance without the water drain hose being connected properly, liquid may leak out of the connecting piece.

▶ Before operating the appliance, connect the water drain hose properly to the connecting piece.

Requirements

- The appliance and the accessory have been unpacked.
 - → "Unpacking the appliance", Page 12
- The appliance is installed at the installation location.
 - → "Requirements for the installation location". Page 13


1. Pull out the condensation hose from the connecting piece.




The condensation hose is connected to the connecting piece at the factory.

Note: When removing the condensation hose, liquid may leak out of the connecting piece.


2. Push the condensation hose into the holder




3. Push the water drain hose as far as it will go into the connecting piece.




4. Empty the condensation container → Page 38.



5. Remove the stopper on the underside.



6. Insert the stopper into the recess in the top.



- Insert the condensation container → Page 39.
- 8. Connect the appliance to the water outlet.
 - → "Water outlet connection types", Page 15

Tip: To collect condensation in the condensation container again (e.g. if you change where the appliance is located), carry out these steps in reverse order.


Water outlet connection types

ATTENTION!

In the event of a blocked or covered outlet, accumulated wastewater can flow back into the appliance.

▶ Before operating the appliance, ensure that the wastewater drains away quickly and eliminate any blockages.


Drainage into a siphon.



Secure the connection point with a (12-22 mm) hose clamp. Secure the water drain hose with a hose guide at a height of at least 80 cm and no more than 100 cm.

Note: You can use the Y-distributor → Page 34 to connect the water drain hose of an additional appliance, such as a washing machine, to the same siphon out-

Drainage into a wash basin.



Push the water drain hose fully through the and secure it using fixing material. Secure the elbow at a height of no more than 100 cm.

Drainage into a gully.




Push the water drain hose fully through the and secure it using fixing material. Secure the elbow to the gully.

4.5 Aligning the appliance

In order to reduce vibrations and noises, align the appliance correctly.

► To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

4.6 Reversing the door

To make it easier to place and remove laundry in the drum, you can change the side on which the door is hinged.

Notes


- Only use a Torx T20 screwdriver to remove and insert screws.
- To prevent material damage, lav the removed door on a level and soft surface.

Removing the door

Requirement: The appliance is disconnected from the mains.


1. Open the door.

2. Unscrew the door.




Changing the door hinge and door hook


1. Unscrew the door hinge and the door hook.




2. Unlock the door ring.




3. Lift the door out of the door ring.




4. Turn the door ring by 180 ① and insert the door into the door ring ②



5. Lock the door ring.




6. Screw on the door hinge and the door hook.




Changing the door lock


1. Unscrew the door lock cover.




2. Remove the door lock.




3. Insert the door lock on the opposite side.



4. Screw on the door lock cover.



5. Screw on the door.



4.7 Connecting the appliance to the electricity supply


 Insert the mains plug of the appliance's power cable in a socket nearby.

- The connection details of the appliance can be found under Technical data \rightarrow *Page* 63.
- 2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

1	Ventilation opening
2	Maintenance flap on the base unit → Page 50
3	Air channel cover (do not remove)
4	Door
5	Condensation container → Page 38
6	Control panel → Page 21




5.2 Wool basket



1	Securing foot
2	Wool basket
3	Insert
4	Tab for securing in the hook

5.3 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.




Programmes → Page 30
 Programme selector → Page 35
 Buttons → Page 26
 Display → Page 23

5.4 Operating logic

In addition to the actual functions of the buttons on the display, you can also use these buttons to select programme settings in the main menu and settings in the sub-menus.

Main menu


To select programme settings, press the buttons above or below the symhols.




The selected programme setting is shown in the middle of the display.

Sub-menu

To select the settings you require, press the buttons below the symbols until the required setting is selected in the display.




To select the settings you require, press the buttons below the symbols until the required setting is selected in the display.



If a setting is activated, the display shows \checkmark . The selection does not need to be confirmed again. The sub-menu closes automatically after a few seconds.

6 Display

The display shows the current settings, options or relevant information.



Example: Display

Display	Designation	Description
0:40 1	Programme duration/programme time remaining	Expected programme duration or programme time remaining in hours and minutes.
20 min	Timed programme	The timed programme is set. → "Timed programmes", Page 32
1:25h ¹	Programme end time	→ "Buttons", Page 28
	Childproof lock	 lights up: The childproof lock is activated. flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 39
a Iron Dry	Dryness level: Iron Dry	The dryness level is activated. → "Buttons", Page 27
□ Cupboard dry	Dryness level: Cupboard Dry	The dryness level is activated. → "Buttons", Page 27
¹ Example		

en Display

Display	Designation	Description
⊞ Cupboard Dry Extra	Dryness level: Cupboard Dry Plus	The dryness level is activated. → "Buttons", Page 27
Adjust dry- ing level	Dryness level adjusted	The adjusted dryness level is activated. → "Dryness level", Page 29
	Gentle drying	Gentle drying is activated for delicate fabrics.
Spin Speed	Washing machine spin speed	The spin speed in rpm that is set on the washing machine is activated.
Please empty condensate container	Condensation container	Empty the condensation container → Page 38. Insert the condensation container → Page 39.
Please clean lint filter	Filter system on the base unit	Clean the filter system on the base unit → Page 36.
Basic ma- chine care re- quired.	Basic appliance care programme	Run the basic appliance care programme. → "Appliance care", Page 47
Refresher-container is empty, please re-fill.	Water tank	Fill the water tank → Page 40 for the crease-removal function.
Cooling	Cooling process	The laundry is cooled while the drum is rotating, in order to avoid damage to the laundry. The process can be cancelled by opening the door. Note: Do not change the programme.
Selfcleaning	Automatic self- cleaning	The automatic self-cleaning function rinses the appliance's heat exchanger. Note: Do not remove the condensation container and do not interrupt the programme.
<u></u>	Wi-Fi	 Lights up: The appliance is connected to your home network. Flashes: The appliance is trying to connect to your home network.
₹ 1.5	Wi-Fi	→ "Home Connect ", Page 42 The appliance is not connected to your home network. → "Home Connect ", Page 42
¹ Example		

Display	Designation	Description
	Remote start	Remote start is activated. → "Buttons", Page 28
©	Energy manager	The appliance is connected to the smart energy system (energy manager).
V ^	Navigation	Selecting settings. → "Operating logic", Page 22
+	Other programme settings	Activate, deactivate or adjust other programme settings. → "Buttons", Page 26
Pause: Continue with 'Start'	Pause	Programme status
Finished, remove washing	End of programme	Programme status
¹ Example		

7 Buttons

Below is an overview of the buttons and their setting options.

With the \oplus button, you can open the sub-menu for additional programme settings. The additional programme settings are listed in the overview for the buttons.

Button	Selection	Description
	StartCancelPause	Start, cancel or pause the programme.
① (mains switch)	Switch onSwitch off	Switch the appliance on or off.
⊕ 3 sec.	ActivateDeactivate	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated. → "Childproof lock", Page 39
	Multiple selection	Activate additional programme settings. → "Adjusting additional programme settings", Page 35 The additional programme settings can be found in this overview.
₿3 sec.	Multiple selection	→ "Basic settings", Page 46

Button	Selection	Description
M1	■ Save ■ Adjust	Press the button for approx. 3 seconds to save your customised programme settings. → "Saving the programme settings", Page 35 Briefly press the button to set customised programme settings for your programme.
M2	■ Save ■ Adjust	Press the button for approx. 3 seconds to save your customised programme settings. → "Saving the programme settings", Page 35 Briefly press the button to set customised programme settings for your programme.
□ ‡	 ■ ☐ Iron Dry ■ ☐ Cupboard dry ■ ☐ Cupboard Dry Extra 	The dryness level defines how damp or dry the laundry is after the programme ends. → "Dryness level", Page 29
<u>a</u>	■ Activate ■ Deactivate	Activate or deactivate the crease-reduction function. Once the programme has ended, the drum moves the laundry at regular intervals for 120 minutes to prevent creasing.

en Buttons

Button	Selection	Description
.	Up to 24 hours	Set the programme end time. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
	ActivateDeactivateOpen the Home Connect menu	→ "Remote start", Page 44

8 Dryness level

Each automatic programme has a specified dryness level. The dryness level defines how dry or damp your laundry is after the programme ends.

Dryness level	Laundry	Drying result
□ Cupboard Dry Extra	Multi-layered, thick laundry that does not dry readily.	The laundry is dry.
□ Cupboard dry	Normal, single-layered laundry.	The laundry is dry.
최 Iron Dry	Normal, single-layered laundry.	The laundry is still slightly damp. To prevent creasing after drying, iron the laundry or hang it up.

8.1 Changing the dryness level

For some automatic programmes, you can change the dryness level so that your laundry will be drier or more damp.

- 1. Set an automatic programme. → "Automatic programmes", Page 30
- The display shows the specified dryness level.
- 2. Press < ¬ ☼ .
- Dry Extra", I "Cupboard dry" or 回 "Iron Dry".

Note: If you change this setting, the change is retained even after the appliance is switched off.

8.2 Adjusting the dryness level

If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level.

- 1. Set an automatic programme. → "Automatic programmes", Page 30
- ▼ The display shows the specified dryness level.
- 2. Press \oplus .
- 3. Select "Adjust dryness level".

Note: If you change this setting, the change is retained even after the appliance is switched off.

9 Programmes

You can dry your fabrics using either an automatic programme or a timed programme.

9.1 Automatic programmes

Automatic programmes are programmes in which humidity sensors measure the residual moisture in the laundry during the drying cycle. The programme only ends once the set dryness level is reached. Each automatic programme has a dryness level → Page 29. The dryness level defines how dry or damp the laundry is after the programme ends.

Tips

- Select the dryness level according to the type of fabric or the desired drying result.
 - → "Dryness level", Page 29
- The laundry's care labels provide you with additional information about programme selection.

Programme	Description	Max. load (kg)
☐ COTTONS	Dry hard-wearing, heat-resistant fabrics made of cotton or linen.	9.0
EASY CARE	Dry items made of synthetic materials or blended fabrics.	3.5
MIX	Dry items made of cotton and synthetics.	3.0
Duvet	Dry clothing, pillows, quilts or bedspreads filled with synthetic fibres.	2.5
	Note: Dry large items of laundry, blankets or pillows individually.	
Lingerie	Dry delicate underwear made of lace, Lycra, satin or blended fabrics.	2.0
Down Wear	Dry clothing, bedspreads or eiderdowns stuffed with down.	1.5
	 Notes ■ Dry large items of laundry, such as blankets or sleeping bags, separately. ■ Once the programme has ended, shake the items of laundry to distribute the stuffing and eliminate any pockets of moisture. ■ If you dry the pillows and the pillows are not completely dry at the end of the programme, dry the pillows with a timed programme. → "Timed programmes", Page 32 	

Programme	Description	Max. load (kg)
HYGIENE	Dry hard-wearing, heat-resistant fabrics made of cotton or linen.	4.0
	Note: Particularly suitable for strict hygiene requirements.	
Outdoor	Dry weatherproof and outdoor clothing with a membrane coating and water-repellent fabrics.	1.5
SHIRTS	Suitable for shirts and blouses made of cotton, linen, synthetics or blended fabrics.	1.5
	Note: For optimal drying results, dry a maximum of 5 shirts or 5 blouses at the same time.	
	Once the laundry is dry, iron it or hang it up. The residual moisture is then distributed evenly.	
SUPER 40	Dry items made of synthetics and light cotton.	1.0
TOWELS	Dry hard-wearing, heat-resistant towels and dressing gowns made of cotton or linen.	6.0
SMART DRY	After you have washed your laundry in the washing machine, the dryer will recommend a suitable programme for drying your laundry.	-
	Note: The washing machine must be Home Connect-capable. The washing machine and dryer must be connected to your home network and registered in your Home Connect app. The selectable programme settings depend on the selected programme.	
ADDITIONAL PRO- GRAMMES	Set additional programmes. The additional programmes can be found in this programme overview. The selectable programme settings depend on the selected programme.	_

9.2 Timed programmes

Timed programmes are programmes with a defined or adjustable programme duration. The programme ends once this time has elapsed, even if the laundry is still not dry, for example. Timed programmes are suitable for drying individual items of laundry or thin fabrics.

Tip: The laundry's care labels provide you with additional information about programme selection.

Programme	Description	Max. load (kg)
Wool Finish	Dry machine-washable items made of wool or containing wool. Note: The laundry becomes fluffier but not dry. Remove laundry once the programme has ended and allow it to dry.	0.5
WOOL IN BASKET	Dry items made of wool or containing wool. Note: Dry these items only using the wool basket. → "Wool basket", Page 41	One item of laundry
BUSINESS &	Reduce creasing and air-borne odours on dry suits, jackets and trousers that have hardly been worn and are labelled as dryclean only. → "Crease-removal function", Page 39 Notes ■ Remove the laundry immediately after the programme has ended to prevent creasing. ■ The laundry is not dried or washed. ■ The programme is not suitable for thin, lightweight summer suits.	One suit or two items of laundry
5 SHIRTS/BLOUSES	Reduce creasing and air-borne odours on shirts and blouses that have been worn once. → "Crease-removal function", Page 39 Notes ■ Remove the laundry immediately after the programme has ended to prevent creasing. ■ The laundry is not dried or washed.	2 to 5 items of laundry

Programme	Description	Max. load (kg)
1 SHIRT/BLOUSE 參	Reduce creasing and air-borne odours on shirts and blouses that have been worn once. → "Crease-removal function", Page 39 Notes ■ Remove the laundry immediately after the programme has ended to prevent	One item of laundry
	creasing. The laundry is not dried or washed.	
Timed Progr. Cold	Dry all types of fabric except for wool and silk. Also suitable for freshening up or airing clothing that has hardly been worn. Note: This programme is suitable for drying using the wool basket. → "Wool basket", Page 41	3.0
TIMED PROGR. WARM	Dry all types of fabric except for wool and silk. Suitable for pre-dried or slightly damp laundry and for drying off multi-layered, thick laundry. Note: This programme is suitable for drying using the wool basket. → "Wool basket", Page 41	3.0
SMART DRY	After you have washed your laundry in the washing machine, the dryer will recommend a suitable programme for drying your laundry. Note: The washing machine must be Home Connect-capable. The washing machine and dryer must be connected to your home network and registered in your Home Connect app. The selectable programme settings depend on the selected programme.	_
ADDITIONAL PRO- GRAMMES	Set additional programmes. The additional programmes can be found in this programme overview. The selectable programme settings depend on the selected programme.	_

10 Accessories

Use original accessories. These have been made especially for your appliance.

Note: Some accessories are available in other colours. Contact → "Customer Service", Page 61.

	Use	Order number
Connection kit with pull- out worktop	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer. The pull-out worktop makes it easier to load and unload the appliance.	WA027400
Y-distributor	Connect the water drain hose of an additional appliance to the same siphon outlet.	15000490
Appliance care product	Spare part for the intensive appliance care function.	00311829

11 Laundry

11.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

 Remove all items from any pockets in your laundry before using the appliance.

Note

The appliance and fabrics are protected when you prepare your laundry.

Brush off sand and soil

- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, Velcro fasteners, hooks and eyes
- Remove curtain fittings and lead strips
- Load the laundry unfolded into the drum
- Spin the laundry before drying
- Dry woollen items, sports shoes and soft toys in the wool basket

→ "Wool basket", Page 41

12 Basic operation

12.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected.

- → "Installation and connection". Page 12
- ► Press ①. The switch-on process takes a few seconds.

Note: The lighting for the drum goes out automatically.

12.2 Setting a programme

- 1. Turn the programme selector and set the required programme.
 - → "Programmes", Page 30
- 2. If required, adjust the programme settings.
 - → "Adjusting the programme settings", Page 35

12.3 Adjusting the programme settings

Depending on the programme and programme progress, you can adjust or activate/deactivate the settings.

Requirement: A programme is set. → "Setting a programme", Page 35

 Adjust the programme settings. → "Buttons". Page 26 Observe the information about operating logic → Page 22.

Note: The programme settings are not saved permanently for the programme.

Adjusting additional programme settings

- **1.** Press \oplus to call up additional programme settings.
- 2. Select the programme settings.
- 3. Press \oplus to call up the main menu.

12.4 Saving the programme settings

You can save your individual programme settings as favourites.

Requirements

- A programme is set.
- The programme settings have been adjusted.
- ▶ Press and hold M1 or M2 for approx. 3 seconds.

Press M1 or M2 to call up the saved programme.

Note: To overwrite the saved programme, repeat the steps above.

12.5 Loading laundry

Note: To prevent creasing, note the maximum load for the programmes. → "Programmes", Page 30

Requirements

- The laundry is prepared and sorted.
 - → "Laundry", Page 34
- The drum is empty.
- 1. Open the door.
- 2. Place the laundry in the drum.
- Close the door. Ensure that there is no laundry trapped in the door.

12.6 Starting the programme

Requirement: A programme is set. → "Setting a programme". Page 35

en operation

- ► Press DII.
- The display shows the programme duration or the programme end time.

Note: If "Cooling" appears, the appliance cools the laundry. When "Cooling" goes out, the laundry has cooled down.

12.7 Adding laundry

After the programme starts, you can remove or add laundry at any time.

1. Press DII.

The cooling process starts automatically after approximately 30 seconds and cools down the laundry while the drum is rotating. If you want to avoid or cancel the cooling process, open the door.

- → "Display", Page 24
- 2. Open the door.
- 3. Add or remove laundry.
- 4. Close the door.
- 5. Press DII.

12.8 Cancelling the programme

- 1. Press DII.
- 2. Open the door.
- Remove the laundry.
 → "Unloading the laundry",
 Page 36

12.9 Unloading the laundry

- 1. Open the door.
- **2.** Remove the laundry from the drum.

12.10 Switching off the appliance

► Press ①.

12.11 Filter system on the base unit

During drying, fluff from the laundry is collected in the base unit's filter system. The filter system protects the appliance from fluff.

Cleaning the filter system on the base unit

If the display shows a notification while the appliance is in operation, clean the base unit's filter system.

Notes

- You can clean the filter regularly system even without the notification being shown on the display. It is not necessary to clean after each drying cycle.
- If you do not clean the appliance as described, the appliance's functionality may be impaired.


Requirement: The display shows the following during operation: "Please clean lint filter".

- **1.** Open the base unit \rightarrow *Page 50*.
- 2. Remove the fluff.




Make sure that you remove all dirt from the seal.

3. Clean the insides thoroughly under running water and then dry them off.




You can remove heavy soiling carefully with a soft brush. Ensure that you thoroughly dry off the filter. If the filter is damp, this may increase the drying time and affect the drying result.

4. Pull the fluff collector out horizontally.




The fluff collector may contain condensation, which may drip out of it when you pull it out.

5. Open the fluff collector and remove any fluff.




6. Clean the filter thoroughly under running water and then dry it off.




You can remove heavy soiling carefully with a soft brush. You must not damage or remove the fluff collector's seal. You can clean the fluff collector in the dishwasher.

7. Close the fluff collector until the tab engages.



8. Slide the fluff collector in horizontally as far as it will go.



9. Close the base unit \rightarrow Page 51.

12.12 Condensation container

Condensation forms during drying, which your appliance uses for automatic cleaning. By default, the condensation is collected in the appliance's condensation container.

Note: Operate this appliance using the water drain hose provided. If you connect the water drain hose \rightarrow Page 14, you do not have to regularly empty the condensation container \rightarrow Page 38.


Emptying the condensation container

If the drying programme has finished or the display shows a notification while the appliance is in operation, empty the condensation container.


Requirements

- The display shows the following after drying: "Finished, remove washing"
- or the display shows the following during operation: "Please empty condensate container".

1. Pull out the condensation container, keeping it level.



2. Empty the condensation container.




Check the condensation container filter → Page 52 regularly and clean the filter if it is dirty. Make sure that you insert the condensation container before operating the appliance.

→ "Inserting the condensation container", Page 39

Inserting the condensation container

 Push the condensation container in as far as it will go.



13 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

13.1 Activating the childproof lock

- ► Press and hold the two A 3 sec. buttons for approx. 3 seconds.
- The control elements are locked.
- ▼ The childproof lock remains active. even after the appliance has been switched off and in the event of a power cut.

13.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

- buttons for approx. 3 seconds.
- ✓ come goes out in the display.

14 Crease-removal function

In order to reduce creasing and airborne odours, such as cigarette smoke, you can use a programme with a crease-removal function for any laundry that has not been worn for long.

14.1 Starting a programme with the crease-removal function

Note

Wash items of laundry that have traces of sweat, perfume or deodorant before wearing them again. Do not use dryer cleaning sets. Do not use a programme with the crease-removal function for the following fabrics:

- Wool, leather and viscose
- Fabrics with parts made from metal, wood or plastic
- Waxed jackets and oilskin jackets

Requirements

- The laundry is prepared.
 - → "Preparing the laundry", Page 34
- The laundry is sorted.
- The laundry is placed in the appliance.
 - → "Loading laundry", Page 35
- 1. Set a programme with crease-removal function.
 - → "Timed programmes", Page 32
- 2. Start the programme.
 - → "Starting the programme", Page 35

If the water tank is empty, the display shows: "Refresher-container is empty, please re-fill.".

→ "Filling the water tank". Page 40

The average programme duration of the crease-removal function is approx. 45 minutes and may be longer or shorter depending on the ambient temperature.

- After the programme has ended, the display shows: "Finished, remove washing".
- Remove the laundry.
 → "Unloading the laundry",
 Page 36

The results of the crease-removal function may vary depending on the type of fabric, the amount of laundry and the selected programme.

- Remove the laundry immediately after the programme has ended to prevent creasing.
- **4.** Hang up the items of laundry and pull them into shape.

14.2 Filling the water tank

Your appliance removes the creases from rarely worn clothing using cold drinking water. If the display shows a notification while the appliance is in operation, fill the water tank.


ATTENTION!

Operating the appliance with water that is dirty or too hot may result in damage to the appliance.

- Only fill the water tank with cold drinking water.
- Never use condensed water, distilled water, additives or descaler for the crease-removal function.

Requirements

- You have started a programme with the crease-removal function.
 → "Starting a programme with the crease-removal function", Page 39
- The display shows: "Refresher-container is empty, please re-fill.".
- The condensation container
 → Page 38 is removed from the
 appliance.
- Add approx. 180 ml cold drinking water through the front opening, using the water jug provided.



Check the water tank filter regularly and clean the filter if it is dirty.

→ "Cleaning the water tank filter",
Page 51

- If "Refresher-container is empty, please re-fill." does not go out on the display, add cold drinking water through the front opening and align the appliance correctly.
- → "Aligning the appliance",
 Page 16
- "Refresher-container is empty, please re-fill." goes out on the display.
- 2 Insert the condensation container. → "Inserting the condensation container", Page 39
- Start the programme.
 → "Starting a programme with the crease-removal function", Page 39


15 Wool basket

Use the wool basket to gently dry delicate fabrics, soft toys or sports shoes in a stationary position.


Note: You can order this optional → "Accessories", Page 34 from our customer service.

15.1 Inserting the wool bas-

- 1. Open the door.
 - Make sure that the drum is empty.
- 2. Insert the feet of the wool basket into the holes in the air channel. cover



3. Insert the tab on the front of the wool basket into the upper hooks.



15.2 Starting a programme with the wool basket


ATTENTION!

If items of laundry in the wool basket touch the rotating drum or the ribs of the drum, the laundry may cause material damage and damage to the appliance.

Place the items of laundry in the insert or wool basket such that they do not touch the drum or the ribs of the drum.

Requirement: The wool basket is inserted into the appliance.

- → "Inserting the wool basket", Page 41
- 1. Place the laundry into the wool basket, either directly or using the insert.
 - → "Examples of how to use the wool basket", Page 42



- 2. Close the door.
- 3. Set a programme that is suitable for drying with the wool basket.
 - Observe the programme description.
 - → "Timed programmes", Page 32
- 4. If required, adjust the duration of the programme.

Observe the recommended programme duration for items of laundry in the wool basket:

Laundry item	Programme duration in hours:minutes
Thin woollen pullover	Approx. 1:20
Thick woollen pullover	Approx. 1:30 - 3:00
Skirt	Approx. 1:00 - 1:30
Trousers	Approx. 1:00 - 1:30
Gloves	Approx. 0:30
Sports shoes	Approx. 1:30/ max. 2:00 with airing

Tip: Increase the programme duration for thick or multi-layered items of laundry.

- **5.** Start the programme \rightarrow Page 35.
- 6. Remove the wool basket once the programme has ended.

15.3 Examples of how to use the wool basket

ATTENTION!


If items of laundry in the wool basket touch the rotating drum or the ribs of the drum, the laundry may cause material damage and damage to the appliance.

Place the items of laundry in the insert or wool basket such that they do not touch the drum or the ribs of the drum.

Example	Use	
Trousers or skirt	Place the items	
	of laundry unfolded into the insert.	
	Note: Spin the laundry before drying.	

Example	Use
Pullover	
Sports shoes	Lift the tongues of the shoes. Remove the insoles or heel cushions. Place a rolled-up hand towel in the wool basket to create an inclined surface. Place the shoes on the towel with the heels facing down. Note: Do not use the insert. Do not dry

Soft toys



Place the soft toy in the wool basket.

leather shoes or

shoes with leather parts.

Note: Do not use the insert. If you place numerous or small soft toys in the wool basket, make sure they do not fall out.

16 Home Connect

This appliance is network-capable. Connecting your appliance to a mobile device lets you control its functions via the Home Connect app, adjust its basic settings and monitor its operating status.

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.gaggenau.com.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information about this at: www.home-connect.com.

The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

Tips

- Please consult the documents supplied by Home Connect.
- Please also follow the instructions in the Home Connect app.

Notes

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app. → "Safety", Page 4
- Operating the appliance on the appliance itself always takes priority. During this time it is not possible to operate the appliance using the Home Connect app.

16.1 Setting up the **Home Connect app**

1. Install the Home Connect app on your mobile device.



2. Start the Home Connect app and set up access for Home Connect. The Home Connect app guides you through the entire login process.

16.2 Setting up Home Connect

Requirements

- The Home Connect app has been installed on your mobile device.
- Wi-Fi has been activated on the router
- The appliance is receiving signals from the WLAN home network (Wi-Fi) at its installation location.
- 1. Use the Home Connect app to scan the QR code.



2. Follow the instructions in the Home Connect app.

16.3 Activating Wi-Fi on the appliance

Note: When Wi-Fi is activated, the energy consumption increases in comparison to the values specified in the consumption value table.

- **1.** Press and hold \Box for approx. 3 seconds.
- 2. Select Wi-Fi on/off.
- 3. Select on.
- Wi-Fi is activated.

Note: If Wi-Fi is activated, the appliance will not switch itself off automatically.

16.4 Deactivating Wi-Fi on the appliance

- **1.** Press and hold \Box for at least 3 seconds.
- 2. Select Wi-Fi on/off.
- 3. Select off.
- ✓ Wi-Fi is deactivated

Note: The connection is automatically re-established when the Wi-Fi is switched back on.

16.5 Resetting the appliance network settings

- 1. Press and hold of for at least 3 seconds.
- 2. Select Network settings .
- 3. Select Reset.
- → The network settings are reset.

16.6 Remote start

Enable the appliance for remote start via the Home Connect app.

Note

Remote start is deactivated for safety reasons in the following circumstances:

- The appliance door is opened.
- DII is pressed.
- □ is pressed.
- The appliance is switched off.
- Following a power cut.

Activating remote start

Requirements

- The appliance is connected to your home WiFi network.
- The appliance is connected to the Home Connect app.
- A programme is selected.
- The appliance door is closed.
- The refresher tank is not empty.
- ► Press 🗇.
- ✓ □ lights up and the appliance is enabled for remote start via the Home Connect app.

Deactivating remote start

- ► Press 🗋 .

16.7 Intelligent programme recommendation

After you have washed your laundry in the washing machine, the dryer will recommend a suitable programme for drying your laundry.

To determine the best drying programme to use, your appliances must transmit and receive information. Observe the following:

 The washing machine must be an appliance with the Home Connect function. The washing machine and dryer must be connected to your home network and registered in your Home Connect app.

Using the intelligent programme recommendation

- 1. Set the **SMART DRY** programme.
- The appliance detects a suitable programme. To cancel or change the programme recommendation, set a different programme or switch the appliance off.
- If the appliance finds a suitable programme, the display for the programme lights up.
- If the appliance does not find a suitable programme, a signal sounds and the display shows "There is no particular drying programme recommended for the last wash programme.".
- 2. If the appliance displays additional information, confirm these notifications in the display.
- The display shows the programme information.
- 3. Press DII.

Note

Why is my dryer unable to recommend a programme?

- No suitable drying programmes for the selected washing programme on the dryer.
- No data is available for the last washing programme used. The data is stored for 24 hours and then deleted.
- The washing programme has been cancelled. The washing programme must run through to the end for analysis to be possible.

16.8 Remote diagnostics

Customer Service can use Remote Diagnostics to access your appliance if you contact them, have your appliance connected to the Home Connect server and if Remote Diagnostics is available in the country in which you are using the appliance.

Tip: For further information and details about the availability of Remote Diagnostics in your country, please visit the service/support section of vour local website: www.home-connect.com.

16.9 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the Wi-Fi communication module installed).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous reset to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time.

Note: Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

17 Basic settings

You can configure the basic settings for your appliance to meet your needs.

17.1 Overview of the basic settings

Basic setting	Description
end signal	Volume of the signal emitted when the programme ends
button signal	Volume of the signal emitted when the buttons are pressed
auto power-off	 Time period until automatic switch-off Activate or de- activate auto- matic switch- off of the appli- ance
Language	Changing the language
Aut. network log- in	Connect the appliance to a WLAN home network (Wi-Fi) with WPS function. → "Setting up Home Connect", Page 43
Man. network log-in	Connect the appliance to a WLAN home network (Wi-Fi) without WPS function. → "Setting up Home Connect", Page 43

Basic setting	Description
Connect to the app	Connect your appliance to the Home Connect app. → "Setting up Home Connect", Page 43
Wi-Fi on/off	Activate or deactivate Wi-Fi. → "Activating Wi-Fi on the appliance", Page 44 → "Deactivating Wi-Fi on the appliance", Page 44
Network settings	Reset the net- work settings. → "Resetting the appliance net- work settings", Page 44
Software update	Install the soft- ware update → "Home Con- nect", Page 42
energy mngmt.	Connect the appliance to the energy manager → "Home Connect", Page 42

17.2 Changing the basic settings

- To call up the basic settings for the sub-menu, press and hold both buttons 3 sec. for approx. 3 seconds.
- 2. Select the required basic setting.

 → "Overview of the basic settings",
 Page 46
- 3. Adjust the basic setting.

4. Press **3 sec.** to call up the main menu.

18 Appliance care

The appliance offers cleaning programmes for basic and intensive appliance care.

18.1 Preparing for appliance care

Preparing the appliance for the appliance care programme

Prepare the appliance before running the appliance care programme.


Requirements

- The drum is empty.
- The appliance is switched off.
- 1. Clean the base unit. → "Cleaning the base unit", Page 51
- 2. Pull out the condensation container horizontally and empty it. → "Emptying the condensation container", Page 38


Preparing the condensation container for the appliance care programme

If you are draining the condensation water from the appliance using the drain hose, prepare the condensation container before running the appliance care programme.

1. Remove the stopper from the recess in the top.



2. Insert the stopper on the underside.



3. Clean the filter in the condensation container.

18.2 Calling up the appliance care programme

Requirement: The appliance care programme is ready.

- → "Preparing for appliance care", Page 47
- 1. Press ①.
 - The switch-on process takes a few seconds.
- 2. Press and hold \(\beta \) 3 sec. for approx. 3 seconds.
- 3. Press the required cleaning programme:
 - Basic appliance care programme

Intensive appliance care programme

18.3 Running the basic appliance care programme

To remove any dirt deposits in the appliance, you can run the basic appliance care programme.

Notes

- The basic appliance care programme runs for approximately 1 hour.
- After a lengthy period of use, the appliance reminds you to run the basic appliance care programme. Before the programme starts or after the programme has ended, the display shows the message "Basic machine care required." . This message appears repeatedly until you have run the basic appliance care programme through to the end.

Requirements

- The appliance care programme is ready.
 - → "Preparing for appliance care", Page 47
- The simple appliance care programme is now called up.
 → "Calling up the appliance care programme", Page 47
- Pour approx. 1.5 litres of hot tap water into the condensation container.
 - Hold the filled condensation container level so that no liquid spills out.
- 2. Insert the condensation container so that it locks into place.
- 3. Press DII.
- The appliance care programme starts and a signal tone sounds.

- "Finished, remove washing" appears on the display and a signal tone sounds once the appliance care programme has ended.
- Pull out the condensation container horizontally and empty it.
 → "Emptying the condensation container", Page 38
- 5. If you are draining the condensation water using the drain hose:
 - Remove the stopper from the underside of the condensation container.
 - Insert the stopper into the recess on the top of the condensation container.
- **6.** Insert the condensation container so that it locks into place.

18.4 Running the intensive appliance care programme

You can run the intensive appliance care programme to remove any stubborn dirt deposits in the appliance and odours after a downtime of more than one month.

Notes

- The intensive appliance care programme runs for approximately 4 hours and must not be cancelled.
- When you run the intensive appliance care programme, you need the original appliance care product.
 - → "Accessories", Page 34

⚠ WARNING Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

 Only use the manufacturer's original spare parts and original accessories.

Starting the intensive appliance care programme

Requirements

- The appliance care programme is ready.
 - → "Preparing for appliance care", Page 47
- The intensive appliance care programme is called up.
 - → "Calling up the appliance care programme", Page 47
- 1. ATTENTION! The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.
- ► Follow the dosage recommendations from the manufacturer.

Pour a bottle of the appliance care product and approx. 1.5 litres of hot tap water into the condensation container.

Hold the filled condensation container level so that no liquid spills out.

- 2. Insert the condensation container so that it locks into place.
- 3. Press DM.
- ▼ The appliance care programme starts and a signal tone sounds.
- ✓ After approx. 3 hours, the appliance pauses the appliance care programme and a message appears on the display informing you that the first part of the appliance care has been carried out.
- 4. Pull out the condensation container horizontally and empty it.
- 5. Pour approx. 1.5 litres of hot tap water into the condensation container.
- **6.** Carefully swing the condensation container horizontally and empty it to rinse out any remaining appliance care product.

Continuing the intensive appliance care programme

- 1. Pour approx. 1.5 litres of hot tap water into the condensation container.
 - Hold the filled condensation container level so that no liquid spills out.
- 2. Insert the condensation container so that it locks into place.
- 3. Press DII.
- ▼ The appliance care programme continues.
- → "Finished, remove washing" appears on the display and a signal tone sounds once the appliance care programme has ended.
- 4. Pull out the condensation container horizontally and empty it.
- 5. If you are draining the condensation water using the drain hose:
 - Remove the stopper from the underside of the condensation container.
 - Insert the stopper into the recess on the top of the condensation container.
- **6.** Insert the condensation container so that it locks into place.

19 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

19.1 Tips on cleaning and care

Wipe down the This ensures the housing and the parts of the applicontrols with ance will remain nothing but water clean and hyand a damp gienic. cloth. Remove all de-Fresh deposits are easier to reteraent residue. sprav residue or move without other residues leaving any immediately. residue. Leave the appli-This allows the ance door open residual water to after use. dry, reducing odours in the appliance.

19.2 Base unit


The base unit is the accessible area at the bottom of the appliance in which you will find the heat exchanger.

Opening the base unit

Requirements


- The appliance has cooled down for 30 minutes.
- The appliance door is closed.

1. Open the maintenance flap.




If you place a cloth beneath the maintenance flap, you can collect the remaining water from the base unit.

2. Open the lever for the heat exchanger cover.




3. Pull out the heat exchanger cover by the handle.



Cleaning the base unit

You can remove any visible dirt in the base unit.

- **1.** Open the base unit \rightarrow Page 50.
- 2. Clean the opening with a soft, damp cloth.




3. Close the base unit \rightarrow Page 51.


Closing the base unit

Requirement: The base unit is open. → "Opening the base unit", Page 50


1. Insert the heat exchanger cover by the handle.



2. Close the lever for the heat exchanger.



3. Close the maintenance flap.



19.3 Water tank filter


The filter in the water tank protects the appliance from dirt and contaminants.

Cleaning the water tank filter


Check the filter regularly and clean the filter if it is dirty.

Requirement: The condensation container → Page 38 is removed from the appliance.

1. Pull out the filter.



- 2. Clean the filter under warm, running water or in the dishwasher.
- 3. Fit the filter.



Insert the condensation container
 → Page 39.

19.4 Moisture sensor

The moisture sensor in this appliance measures how damp the laundry is during the drying cycle. The appliance changes the duration of the automatic programme depending on the residual moisture in the laundry.

Cleaning the moisture sensor

Over time, residue from limescale, detergents and care products can build up on the moisture sensor. Clean the moisture sensor regularly.


ATTENTION!

Hard or rough objects may damage the moisture sensor.

 Do not use hard or rough objects, abrasive cleaning products or steel wool for cleaning.

Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.

- 1. Open the door.
- Clean the moisture sensor with a sponge.




19.5 Condensation container filter

During drying, fluff from the laundry gets into the condensation. The filter in the condensation container protects the appliance from fluff.


Clean the filter for the condensation tank.

The filter is cleaned automatically when the condensation container is emptied. Check the filter regularly and clean the filter if it is dirty.


1. Empty the condensation container. → "Emptying the condensation container", Page 38



2. Remove the filter.



- 3. Clean the filter under warm, running water or in the dishwasher.
- 4. Slide in the filter as far as it will go.



5. Insert the condensation container. → "Inserting the condensation container", Page 39

20 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

⚠ WARNING

Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ► If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting
"Cooling" and the drum rotates.	Cooling process active.Not a fault.Do not change the programme during the cooling process.
	Note: The cooling process takes up to 10 minutes. You can continue to operate the appliance.
Humming noise.	Compressor active. ► Not a fault – normal operating noise.
The display goes out and DIII flashes.	Energy-saving mode is active▶ Press any button.✔ The symbol lights up again.
"Basic machine care required."	 After a period of operation, the appliance automatically recommends that you run the basic appliance care programme. ▶ Running the basic appliance care programme on the appliance. → "Appliance care", Page 47
The crease-removal function takes too long.	A low ambient temperature extends the duration of the crease-removal function. Not a fault – no action required.
"Please clean lint fil- ter"	The base unit's filter is soiled. ► → "Cleaning the filter system on the base unit", Page 36
The appliance is not working.	The mains plug of the power cord is not plugged in. Connect the appliance to the power supply.
	The circuit breaker in the fuse box has tripped.

Fault	Cause and troubleshooting
The appliance is not	► Check the circuit breaker in the fuse box.
working.	There has been a power cut. ► Check whether the lighting in your kitchen or other appliances are working.
Appliance paused, but the drum is rotating.	Cooling process active. Not a fault – no action required.
Home Connect is not working properly.	Different causes are possible. • Go to www.home-connect.com.
No connection to the home network.	Wi-Fi is switched off. ► Activating Wi-Fi on the appliance. → "Activating Wi-Fi on the appliance", Page 44.
	 Wi-Fi is activated but a connection to your home network cannot be established. 1. Ensure that the home network is available. 2. Reconnect the appliance to the home network.
Creasing.	The load is too large. ► Observe the maximum load capacity of the → "Programmes", Page 30.
	The laundry lies in the drum for too long after drying.1. Remove the laundry from the drum as soon as the drying programme has finished.2. Spread the items of laundry for cooling.
	Unsuitable programme for the type of fabric. ► Set the suitable programme for the type of fabric. → "Programmes", Page 30
	Easy-Care fabrics are dried for too long. ► → "Changing the dryness level", Page 29. ► → "Adjusting the dryness level", Page 29.
	Anti-Crease not activated. ► Activate the Anti-Crease function. → "Buttons", Page 27
"Please empty con- densate container" and programme ter- minated.	Condensation tank filled. 1. → "Emptying the condensation container", Page 38. 2. → "Inserting the condensation container", Page 39. 3. → "Starting the programme", Page 35.
	Water drain hose is caught or jammed. 1. Ensure that the water drain hose is not kinked or

trapped.

Fault	Cause and troubleshooting
"Please empty con-	2 Route the water drain hose without kinks.
densate container" and programme terminated.	Water drain hose is not connected correctly. ► Ensure that the water drain hose is connected correctly. → "Connecting the water drain hose", Page 14
	Water drain hose is blocked. ► Rinse the water drain hose with tap water.
	The filter for the condensation tank is soiled. ► → "Clean the filter for the condensation tank.", Page 52.
	Foreign object is located in the base unit 1. → "Opening the base unit", Page 50. 2. Remove the foreign objects that are present. 3. → "Closing the base unit", Page 51.
	Dirt in the appliance. ► Run the intensive appliance care programme. → "Appliance care", Page 47
Condensation in the condensation tank even though the water	The appliance uses condensation for the automatic self-cleaning. ► Not a fault – no action required.
drain hose is connected.	Water drain hose is not connected correctly. ► Ensure that the water drain hose is connected correctly. → "Connecting the water drain hose", Page 14
The programme does not start.	Childproof lock is activated. ► → "Deactivating the childproof lock", Page 39
	DII has not been pressed. ► Press DII.
	No programme set. 1. → "Setting a programme", Page 35. 2. → "Starting the programme", Page 35.
The length of the programme changes during the drying cycle.	The programme operation is optimised electronically. This may change the programme duration. ▶ Not a fault – no action required.
Pumping noise.	Condensation pump active. Not a fault – normal operating noise.
Buzzing noise.	Compressor ventilation active. Not a fault – normal operating noise.

Fault	Cau
The drying time is too	The
long.	▶ →

ise and troubleshooting

base unit's filter is soiled.

"Cleaning the filter system on the base unit". Page 36

The ambient temperature is greater than 30 °C.

 Ensure that the ambient temperature is below 30 °C.

The ambient temperature is lower than 15 °C.

► Ensure that the ambient temperature is above 15 °C.

Insufficient air circulation at the appliance's installation location.

Ventilate the appliance's installation location.

Insufficient condensation for the automatic self-cleaning when permanently drying small loads of laundry.

► Regularly dry a load weighing more than 3 kg of damp laundry until the programme ends.

Insufficient condensation for the automatic self-cleaning when permanently using the crease-removal function.

 Regularly dry a load weighing more than 3 kg of damp laundry until the programme ends.

The appliance's ventilation opening is blocked.

 Ensure that the ventilation opening of the appliance is kept clear.

Heat exchanger is soiled.

- Running the basic appliance care programme on the appliance.
 - → "Appliance care", Page 47

The base unit filter is damp.

- 1. → "Cleaning the filter system on the base unit", Page 36.
- **2.** Dry the filter thoroughly after cleaning.
- 3. \rightarrow "Closing the base unit". Page 51.
- **4.** → "Switching off the appliance", Page 36.
- 5. → "Switching on the appliance", Page 35.
- **6.** \rightarrow "Starting the programme", Page 35.

"Ready in" time is activated and the ambient temperature is lower than 16 °C.

- ► Ensure that the ambient temperature is above 16 °C or start the next drying process within 2 hours.
 - → " Technical data", Page 63

Fault	Cause and troubleshooting
The drying time is too long.	Remote start is activated and the ambient temperature is lower than 16 °C. ► Ensure that the ambient temperature is above 16 °C or start the next drying process within 2 hours. → " Technical data", Page 63
"Please clean lint filter" and the appliance is not responding to operation.	 The ambient temperature is low and the base unit filter is damp. 1. → "Cleaning the filter system on the base unit", Page 36. 2. Dry the filter thoroughly after cleaning. 3. → "Closing the base unit", Page 51. 4. → "Switching off the appliance", Page 36. 5. → "Switching on the appliance", Page 35. 6. → "Starting the programme", Page 35.
"Selfcleaning"	Automatic self-cleaning function rinses the appliance's heat exchanger. 1. Not a fault. 2. Do not pull out the condensation tank. 3. Do not cancel the programme.
Water is leaking from the appliance.	Appliance is not correctly aligned. ► → "Aligning the appliance", Page 16
	The seal for the heat exchanger cover is dirty. ► Clean the seal for the heat exchanger cover. → "Cleaning the filter system on the base unit", Page 36
	Water drain hose is not connected correctly. ► Ensure that the water drain hose is connected correctly. → "Connecting the water drain hose", Page 14
	The lever for the heat exchanger cover is not closed correctly. ► Ensure that the lever for the heat exchanger cover is closed correctly. → "Closing the base unit", Page 51
"Refresher-container is empty, please re- fill."	The water tank for the crease-removal function is empty. ► Fill water tank. → "Filling the water tank", Page 40.

Odours have formed in the appliance.

Stubborn dirt in the appliance or an extended appliance downtime of more than one month.

► Run the intensive appliance care programme.

3. → "Starting the programme", Page 35.

→ "Appliance care", Page 47

21 Transportation, storage and disposal

21.1 Preparing the appliance for transportation

ATTENTION!

If the appliance is operated immediately after transportation, the refrigerant contained in the appliance may result in damage to the appliance.

► Immediately after transporting the appliance, leave it to rest for two hours before putting it into operation.

Tip: The appliance may contain residual water, which may drip out of it when transported. The appliance should be transported upright.

Requirements

- The condensation container is emptied. Emptying the condensation container → Page 38
- The appliance has been switched
 - → "Switching on the appliance", Page 35
- 1. Set any programme → Page 35.
- 2. Start the programme → Page 35 and wait 5 minutes.
- The condensation is drained.
- **3.** Switch off the appliance. → "Switching off the appliance", Page 36
- 4. Remove the water drain hose from the connection point.
 - → "Water outlet connection types", Page 15
- 5. Secure the water drain hose on the appliance against unintentional loosening.
 - Ensure that you do not bend the water drain hose.

- 6. Empty the condensation container → Page 38.
- 7. Insert the condensation container → Page 39.
- 8. Disconnect the appliance's mains plug from the power supply.
- ✓ The appliance is now ready to be transported.

21.2 Disposing of old appliance

Valuable raw materials can be reused by recycling.

⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from openina.
- ► With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

⚠ WARNING Risk of fire!

The refrigerant R290 used in this appliance is environmentally friendly. It is however flammable and may ignite if appliances are not disposed of properly.

- Dispose of the appliance properly.
- ► Do not damage the tubing of the refrigerant circuit.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner.

Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

22.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again auickly.

22 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

23 Consumption values

The programme

 □ COTTONS +
 □ "Cupboard dry" (denoted by the arrow symbol) is suitable for drying cotton laundry with a normal dampness level, and is the most efficient programme for drying damp cotton laundry in terms of combined energy consumption.

The consumption values for this programme that are declared on the energy label refer to a moisture content of the laundry of 60%.

The values given for other programmes are indicative only and were determined in accordance with the applicable standard EN61121.

The actual values may deviate from the indicated values depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric, set degree of dryness, amount of laundry being loaded, environmental conditions and the activation of additional functions.

The expected programme duration/"Ready in" time that is shown on the appliance display when selecting the programme is based on the spin speed in the washing machine of 1000 rpm when the appliance is delivered.

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
□ COTTONS + □ □ Cupboard dry	0.0	9.0	1400	50	3:12	1.37
□ COTTONS + □ □ Cupboard dry	0.0	4.5	1400	50	1:59	0.77
□ COTTONS + □ □ Cupboard dry	0.0	9.0	1000	60	3:35	1.61
□ COTTONS + □ □ Cupboard dry	0.0	4.5	1000	60	2:12	0.90
□ COTTONS + □ Cupboard dry	0.0	9.0	800	70	3:58	1.85
□ COTTONS + □ □ Cupboard dry	0.0	4.5	800	70	2:25	1.03
☐ COTTONS + △	12.0	9.0	1400	50	2:23	0.97
☐ COTTONS + △	12.0	4.5	1400	50	1:26	0.54
☐ COTTONS + ≥ Iron Dry	12.0	9.0	1000	60	2:46	1.21

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
COTTONS + △ Iron Dry	12.0	4.5	1000	60	1:39	0.67
☐ COTTONS + ☐ Iron Dry	12.0	9.0	800	70	3:09	1.45
☐ COTTONS + ☐ Iron Dry	12.0	4.5	800	70	1:52	0.80
EASY CARE + 🖽 Cupboard dry	2.0	3.5	800	40	1:17	0.44
EASY CARE + 匝 Cupboard dry	2.0	3.5	600	50	1:27	0.53

Appliance height	84.2 cm
Appliance width	59.8 cm
Appliance depth	61.3 cm
Appliance depth with door closed	65.1 cm
Appliance depth with door open	110.5 cm
Weight	58.4 kg
Maximum load	9.0 kg
Mains voltage	220-240 V, 50 Hz
← Minimum in- stallation protec-	10A

600 W

Off mode:

0.10 W

0.10 W

Left-on mode:

24 Technical data

tion

tion

Nominal power

Power consump-

Ambient temperature	Minimum:5 °CMaximum:35 °C
Length of the power cord	145 cm

This product contains light sources from energy efficiency class F. These light sources are available as a spare part and must only be replaced by trained specialist staff.

You can find more information about your model online at https:// eprel.ec.europa.eu/1. This web address is linked to the official EU EPREL product database. Please then follow the instructions on searching for the model. The model identifier is made up of the characters before the slash in the product number (E-Nr.) on the rating plate. Alternatively, you can also find the model identifier in the first line of the EU energy label.

Only applies to countries in the European Economic Area

25 Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality conforms to the basic requirements and other relevant provisions of Directive 2014/53/ EU.

A detailed RED Declaration of Conformity can be found online at www.gaggenau.com among the additional documents on the product page for your appliance.



Hereby, BSH Hausgeräte GmbH declares that the appliance with Home Connect functionality is in compliance with relevant statutory requirements.1

A detailed Declaration of Conformity can be found online at www.gaggenau.com/gb among the additional documents on the product page for your appliance.1

UK CA

Only applies to Great Britain 2.4 GHz band (2400-2483.5 MHz): Max. 100 mW 5 GHz band (5150-5350 MHz + 5470-5725 MHz): Max. 100 mW

	BE	BG	CZ	DK	DE	EE	ΙE	EL	ES
	FR	HR	ΙΤ	CY	LI	LV	LT	LU	HU
	MT	NL	AT	PL	PT	RO	SI	SK	FI
	SE	NO	СН	TR	IS	UK (NI)			
5 GHz WLAN (Wi-Fi): For indoor use only.									
AL	ВА		1D	ME	MK	RS	UK		UA
5 GHz WLAN (Wi-Fi): For indoor use only.									

Only applies to Great Britain







Gaggenau Hausgeräte GmbH Carl-Wery-Straße 34 81739 München GERMANY www.gaggenau.com Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom



