

ACCESSORIES

2026/2027

GAGGENAU

TO COOK A PERFECT DISH, YOU NEED MORE THAN A GOOD RECIPE

Optimized cooking routines ease preparation and allow you to focus on your creative talents. Inspired by the streamlined workflow of a professional kitchen, Gaggenau has developed accessories that enhance the appliances and, in the end, a home chef's masterpiece. Let the artistry begin.



Exclusively for our in-home chefs. With different vacuum levels and sizes of bags, you will be able to lock in flavors, preserve ingredients and marinade in a third of the time. With the ability to vacuum outside of the drawer you can also enjoy opened wine even after the following night.



From cooktop to Teppan Yaki. With these unique Gaggenau accessories, available in two different sizes, induction cooktops can easily be converted into a Teppan Yaki. Inspired by Japanese cuisine, "teppanyaki" style cooking is a healthy and exciting way to prepare a delicious meal.



Breads are one of the simplest foods, yet difficult to achieve in any but the best ovens. The use of the baking stone, which is capable of up to 570 °F, is the secret to a crisp crust and soft inside. It also makes the perfect Tarte Flambée and flat breads.



Versatile and practical. The latest combi-steam ovens offer an enlarged cavity with which to master the culinary style. It not only steams, but braises, bakes, browns, gratinates, regenerates, sous-vides and even extracts juice. Keeping your stainless steel interior pristine is as simple as inserting a cartridge and starting the automatic cleaning program.

Single ovens

For use with 24" **GO 470/471** ovens

BA 020 110

Air frying tray.
1" (30 mm) deep.



BA 026 116

Baking tray, enameled.
1" (30 mm) deep.



BA 026 117

Broil pan, enameled.
1 1/2" (38 mm) deep.



BA 036 166

Wire rack, chromium-plated.
Without opening, with feet.



BA 016 106

Pull-out rack.
Available to order mid-2026



BA 046 118

Glass tray.
1" deep (24 mm).



BA 056 134

Baking stone.
Incl. baking stone support and baking
paddle.
Not in combination with pull-out
system.



BS 020 003

Baking paddle.
Serving and cutting board.



GN 340 231

Gastronorm roaster in cast aluminum.
GN 2/3, height 6 1/2" (165 mm),
PFAS free non-stick coating.
Lower and upper part can also be
used as separate ovenproof dishes,
3 15/16" (100 mm) and 2 9/16" (65 mm)
deep.



For use with 30" **GO 480/481 721**

BA 020 110

Air frying tray.
To be placed on wire rack.



BA 028 115

Baking tray, enameled.
1" (30 mm) deep.



BA 038 165

Wire rack, chromium-plated.
Without opening, with feet.



BA 018 106

Pull-out rack.
Available to order mid-2026.



BA 058 134

Baking stone.
Incl. baking stone support and baking
paddle.
Not in combination with pull-out
system.



BS 020 003

Baking paddle.
Serving and cutting board.



GN 340 231

Gastronorm roaster in cast aluminum.
GN 2/3, height 6 1/2" (165 mm),
PFAS free non-stick coating.
Lower and upper part can also be
used as separate ovenproof dishes,
3 15/16" (100 mm) and 2 9/16" (65 mm)
deep.



For use with 36" **EB 333** oven

BA 090 100

Black rotary knobs for EB333,
set of 2 Stainless steel knobs with
black coating.



BA 018 165

Pull-out system.
Fully extendable telescopic rails and
enameled cast iron frame.



BA 028 115

Baking tray, enameled
1" deep.



BA 038 165

Wire rack, chromium-plated.
Without opening, with feet.



BA 058 115

Heating element for baking stone and
Gastronorm roaster



BA 058 135

Baking stone
Incl. baking stone support and pizza
peel (heating element must be
ordered separately).
Cannot be used in combination with
pull-out system.



Combi-steam ovens

For use with 24" **GS 470/471 720** and 30" **GS 460/461 720, GS 480/481 720** Combi-steam ovens

BA 010 050

Core temperature probe.
Compatible with GO, GS, GM.



BA 010 301

Triple telescopic pull-out rack for
combi-steam ovens.



BA 020 361

Cooking container, stainless steel,
unperforated, 1 13/16" deep (46 mm),
4.8 qt. (5.4 l).



BA 020 370

Cooking container, stainless steel,
perforated, 1 9/16" deep (40 mm),
4.4 qt. (5 l).



BA 020 382

Cooking container, unperforated,
PFAS free non-stick coating,
1 13/16" deep (46 mm), 4.8 qt. (5.4 l)



BA 020 391

Insert, perforated, PFAS free non-stick
coating, 1 9/16" deep (40 mm),
4.4 qt. (5 l).



BA 046 118

Glass tray.
1" deep (24 mm).



GN 010 330

Adapter for gastronorm insert and
roaster.



GN 114 130

Gastronorm insert, stainless steel,
GN 1/3.
Unperforated, 1 9/16" deep (40 mm),
1.3 qt. (1.5 l).



GN 114 230

Gastronorm insert, stainless steel,
GN 2/3.
Unperforated, 1 9/16" deep (40 mm),
2.6 qt. (3 l).



GN 124 130

Gastronorm insert, stainless steel,
GN 1/3.
Perforated, 1 9/16" deep (40 mm),
1.3 qt. (1.5 l).



GN 124 230

Gastronorm insert, stainless steel,
GN 2/3.
Perforated, 1 9/16" deep (40 mm),
2.6 qt. (3 l).



GN 340 231

Gastronorm roaster in cast aluminum
GN 2/3, height 6 1/2" (165 mm),
PFAS free non-stick coating.
Lower and upper part can also be
used as separate ovenproof dishes,
3 15/16" (100 mm) and 2 9/16" (65 mm)
deep.



Use in combi-steam ovens in
combination with adapter GN 010 330
and pull-out system BA 010 301.

CLS 100 40

Cleaning cartridges, set of 4



Part No. 17002490

Descaling tablets, set of 4.



Part No. 00578813

Vacuuming bags, small
7" x 11", 100 pcs.

For use with the vacuuming drawers
GV 451



Part No. 00578814

Vacuuming bags, large
9 1/2" x 14", 100 pcs.

For use with the vacuuming drawers
GV 451.



ACCESSORIES

Cooktops

For use with **Vario cooktops**

WP 400 001

Wok pan
Multiple-layered material
With round bottom and handle
ø 14 ³/₁₆" , 5.3 quarts, height 3 ¹⁵/₁₆" .
For use with 400 series VI 414 induction wok and VI 492 cooktops.



WZ 400 000

Wok support ring for wok pan
Necessary for use with 400 series
VI 414 induction wok and VI 492
cooktop.



LV 030 000

Lava Rock
Lava stones for refilling
For use with the VR 414 and VR 230.



AA 414 010

Air Deflector
For VL 414 next to gas appliance.



For use with **induction and flex induction cooktops**

CA 051 301

Teppan Yaki made of multi ply material,
16" x 10" .
For use with CI 282/292 flex induction,
CX 482/492 (including Teppanyaki mode),
VI 422 and VI 492 cooktops.
(Available from September 2024)



GN 232 110

Teppan Yaki
Multi-ply material
13" x 21" , GN ¹/₂ .
For use with CX 482/492
(including Teppanyaki mode).



CA 230 100

Stainless steel knob
With black coating
For CI 282/292 flex induction cooktops.



CA 060 600

Cooking sensor for temperature
regulation with pots.
For use with CX 482/492 and
CI 282/292 flex induction cooktops.



For use with **gas cooktops**

WP 400 001

Wok pan
Multiple-layered material
With round bottom and handle
ø 14 ³/₁₆" , 5.3 quarts, height 3 ¹⁵/₁₆" .
For use on center wok burner of VG 295,
VG 491 gas cooktops, VG 231 gas
cooktop and VG 415.



Coffee machines

For use with **24" GC 461/451 720**

GA 022 720

Cleaning cartridge.
Lifespan approx. 9 months.



GA 022 740

Descaling cartridge.
Lifespan approx. 9 months.



Part No. 12043068

Milk container.



Refrigeration

For use with 18" wine storage unit **RW 414**

RA 492 160

Removable shelf with oak wood frame. Suitable for decanters and open bottles.




RA 493 060

Presenter in oak wood and aluminum in anthracite for single bottle display. 1 piece.



RA 491 161

Fully extendable bottle trays with hidden telescopic rails in oak wood and solid aluminum in anthracite.



RA 498 140

Bottle support in oak wood for convenient storage of bottles on the division plate.



RA 430 000

Screw hole cover set. 8 pieces.



For use with 24" wine storage unit **RW 466**

RA 492 660

Removable shelf with oak wood frame. Suitable for decanters and open bottles.




RA 493 060

Presenter in oak wood and aluminum in anthracite for single bottle display. 1 piece.



RA 491 661

Fully extendable bottle trays with hidden telescopic rails in oak wood and solid aluminum in anthracite.



RA 498 640

Bottle support in oak wood for convenient storage of bottles on the division plate.



RA 430 000

Screw hole cover set. 8 pieces.



For use with refrigerators **RC 462/472/492, RVB 477/497** and **RVY 497**

RA 430 100

Storage container with transparent lid, anthracite.

To add the egg insert, please order Part #11031964 in addition to the container.



RVA 438 040

Bottle support in oak wood with magnetic connector



Part #11037377

Water filter bypass for home water filtration system.



Part #17006999

Ethylene absorber.

For placement in a fresh cooling drawer.



Part #17007000

Ethylene absorber refill kit.

For placement in a fresh cooling drawer.



RA 450 022

Activated charcoal water filter
For RVY, RVB and RF.



Dishwashers

DA 042 030

Sterling silver cutlery cassette.

Aluminum silver care cassette to protect corrosion of silver cutlery. Easy placement of cartridge in the cutlery basket.

W x H x D in inches: 2 1/16" x 8 9/16" x 1 7/8".



DA 043 000

Holder for long-stemmed glasses.

Offers safe positioning for up to four longstemmed glasses during the wash cycle and ensures optimal cleaning results. For positioning in the lower rack.



DA 045 060

3rd basket.

3rd loading level above the upper basket. For small bowls, cups and cooking utensils. Movable knife shelf.

Only for use with DF 211 dishwasher.



DA 045 061

3rd basket.

With smooth running rails.

3rd loading level above the upper basket. For small bowls, cups and cooking utensils. Movable knife shelf.

Only for use with DF 481/DF 481F dishwasher.



The difference is Gaggenau



Gaggenauofficial



gaggenau_



showcase/gaggenau/



gaggenauofficial

gaggenau.com