



en

Please observe

Electrical connection

The appliance must only be connected to a properly installed protective contact socket. The installation of the socket or replacement of the connecting cable must only be carried out by a qualified electrician in accordance with current regulations. The appliance must only be connected with the power cable provided. Connect the power cable to the back of the appliance. Power cables with various plug types are available from our after-sales service.

Do not use multi-plug adapters, power strips or extension leads. There is a risk of fire in the event of overloading.

If the plug is no longer accessible subsequent to installation, an all-pole disconnecting device must be present on the installation side with a contact gap of at least 3 mm.

Fitted units

The fitted cabinet must not have a back panel behind the appliances. There should be a gap of at least 20 mm between the wall and the cabinet base as well as the rear panel of the cabinet situated above.

Do not install the appliance behind the door of a unit.

Ventilation slots and intake openings must not be covered.

Read the information in the installation instructions for the appliance installed above.

Installing the appliance

Connect the appliance to the mains. Then align the appliance flush with the units and screw it in place.

Note: Ensure that the connector lead does not become trapped or bent. After installation, the connector lead must not be in contact with the back or the base of the appliance.

After installation, the connector lead must not be in contact with the back or the base of the appliance.

fa

لطفاً در نظر داشته باشید

اتصال به برق

دستگاه فقط باید به یک پریز برق دارای محافظ که به شکل صحیح نصب شده است، متصل شود. نصب پریز یا تعویض کابل اتصال باید تنها توسط یک متخصص مجاز و با رعایت مقررات مربوطه صورت گیرد. دستگاه باید تنها توسط کابل برق ارائه شده به برق متصل شود. کابل برق را به پشت دستگاه وصل کنید.

کابل‌های برق با دوشاخه‌های گوناگون را می‌توانید از مرکز خدمات پس از فروش ما تهیه کنید.

از کابل تقسیم، سه راهی برق یا کابل رابط استفاده نکنید. بار اضافه الکتریکی خطر آتش‌سوزی به همراه دارد.

در صورتی که پریز برق بعد از نصب دستگاه دیگر در دسترس نباشد، باید یک کلید قطع جریان برای تمام قطب‌ها تعبیه شود که بعد از قطع جریان بین دو انتهای سیم حداقل 3 میلی‌متر فاصله بیندازد.

کابینت‌های مناسب

کابینت محل نصب نباید دارای دیواره عقبی در پشت دستگاه باشد. بین دیوار و کف کابینت و نیز دیواره پشتی کابینت بالایی باید حداقل 20 میلی‌متر فاصله باشد.

دستگاه را پشت درب یک کابینت نصب نکنید.

شیرهای تهویه و دهانه‌های ورودی هوا نباید پوشیده شوند.

اطلاعات موجود در راهنمای نصب دستگاهی را که در بالا نصب می‌شود مورد توجه قرار دهید.

نصب دستگاه

دستگاه را به برق وصل کنید. سپس دستگاه را با کابینت‌ها هم سطح نموده و آنرا در محل خود پیچ کنید.

توجه: مطمئن شوید که سیم اتصال گیر نکند یا خم نشود. کابل اتصال نباید بعد از نصب با پشت یا کف دستگاه در تماس باشد.

کابل اتصال نباید بعد از نصب با پشت یا کف دستگاه در تماس باشد.

