



**BOP210101**

#### Included accessories

1 x enamel baking tray, suit. pyrolytic clean  
1 x grill shelf  
1 x grill tub

#### Optional accessories

**BA036102:**  
Wire shelf, for oven BOP21\*

**BA046115:**  
Glass tray, for 60cm oven

**BA056115:**  
Heating elem. 230 V, for 60cm oven

**BA056130:**  
Baking stone for 60 cm oven

**BA216102:**  
4 telescopic shelf rails

**BA226102:**  
Grill tray, for oven BOP21\*

**BA226112:**  
Baking tray, for oven BOP21\*

**BS020002:**  
Set of 2 pizza paddles

#### installation accessories

**Built-in oven 200 series**  
**60 x 60 cm, door hinge: right, Gaggenau**  
**Anthracite**  
**BOP210101**

Flush installation  
9 heating methods, with baking stone function  
TFT touch display  
Panel-free appliance with surface control module  
Electronic temperature control from 50 °C to 300 °C  
76 litres net volume

#### Heating methods

Hot air. Eco hot air. Top + bottom heat. Top heat. Bottom heat. Hot air+ bottom heat. Full surface grill + circulated air. Full surface grill. Baking stone function.

#### Handling

Rotary knob and TFT touch display operation.  
Option to save individual recipes.  
Information key with use indications.  
Side-opening door opens up to 110° angle.

#### Features

Baking stone socket.  
Actual temperature display.  
Rapid heating.  
Timer functions: cooking time, cooking time end, timer, stopwatch, long-term timer.  
60 W halogen light on the top.  
Chromium-plated side shelf supports with 4 tray levels.

#### Safety

Thermally insulated door with triple glazing.  
Child lock.  
Safety shut-off.  
Cooled housing with temperature protection.

#### Cleaning

Gaggenau enamel.  
Heated air cleaning catalyser.

#### Planning notes

Door hinge not reversible.  
The door panel surface of the appliance extends 21 mm from the furniture cavity.  
The outer edge of the door handle extends 72 mm from the furniture cavity.  
Necessary lateral gap between appliance door and furniture panel of min. 5 mm.  
Consider the overhang, incl. the door handle, when planning to open drawers next to the appliance.  
When planning a corner solution, pay attention to the 110° door opening angle.  
For installation underneath cooktops: Distance between the underside of the cooktop and the top edge of the oven cavity: min. 15 mm. The planning notes for the cooktops (particularly regarding ventilation, gas/electric connection) must be taken into account.  
To achieve the 550 mm installation depth, the connection cable needs to follow the slanted edge on the corner of the housing.  
The mains socket needs to be planned outside of the built-in niche.

#### Connection

Total connected load 3.7 KW.  
Plan a connection cable.

