

DF261101



1 x baking tray spray head 1 x stainless steel trim kit

DA043000:

Holder for long-stemmed glasses

DA045060:

3. Basket

DA041061:

Cutlery Drawer

DA042030:

Silver polishing cassette

DA021000:

Retractable hinge f. high corpus dimens.

GH045010:

Handle ss 45 cm

GZ010011:

inlet and outlet hose extention

Dishwasher 200 series

60 cm

DF261101

- Optimal protection for sensitive glassware
- 6 programmes with aqua sensor and 3 options, such as Power for cleaning and drying dishes from 57 minutes and Intensive for particularly thorough cleaning in the lower basket
- Home Connect
- Optimal protection for sensitive glassware by low temperature drying with zeolite, elaborated basket design and intelligent water softening

6 programmes with aqua sensor and 3 options, such as Power for cleaning and drying dishes from 57 minutes and Intensive for particularly thorough cleaning in the lower basket

Flexible basket system

Bright interior light

Remaining time projection onto the kitchen floor Very quiet: 43 dB

Handling

TFT display indicating remaining or end time, refill for salt and rinsing agent, inflow of water. Touch key operation.

Flexible cycle time reduction, even during an active cycle.

Drying assistant for optional door opening at the end of the programme (only available with active Home Connect functionality).

Personalisation function for saving individual combinations of programmes.

Information key with use indications.

Time delay up to 24 hours.

Visual and acoustic end of programme indicator. Remaining time projection.

Features

Bright interior light.

Glass protection with zeolite.

Aqua sensor.

Load sensor.

Automatic detergent function.

Regeneration electronics.

Heat exchanger.

Continuous flow heater.

Triple filter system, self-cleaning.

Soft lock.

Aqua stop.

Selected digital services (Home Connect)

Programme assistant.

Temporary noise reduction.

Drying assistant for optional door opening at the end of the programme.

Downloadable programmes.

Integrated WiFi module for digital services (Home Connect).

The availability of the Home Connect functionality depends on the availability of the Home Connect Services in your country. Home Connect Services are not available in every country – for further information please check: www.home-connect.com

Programmes

6 programmes:

Auto 35 °C - 45 °C. Auto 45 °C - 65 °C. Auto

65 °C - 75 °C. Eco 50 °C. Quick wash 45 °C (35 min.). Personalisation function (default setting: Pre-rinse).

3 options:

Intensive, Power, Half Load,

Machine Care.

Interior

Flexible basket system.

Upper basket:

Over extension. Optional extra cleaning area by activating additional spray nozzles. Rackmatic with 3 levels, adjustable in height up to 5 cm. 6 folding spines. 4 folding racks for optimal protection of glass.

Lower basket:

8 folding spines. 2 folding racks for optimal protection of glass. Dividable glass support. Cutlery basket.

Maximum dish sizes (upper/lower basket) 29/28, 26.5/30.5 or 24/34 cm respectively. 13 place setting capacity.

Maximum glass loading capacity 23 wine glasses.

Product rating

Energy efficiency class B at a range of energy efficiency classes from A to G.

From 9.5 I water.

From 0.635 kWh.

Noise level 43 dB (re 1 pW).

Planning notes

Height-adjustable feet.

Appliance plinth recess 100 mm (see drawing). To display the remaining time projection, a minimum plinth protrusion must be present (40 mm + thickness of the furniture front).

The maximum plinth height must be reduced by 30 mm to provide an optimal display of the remaining time projection.

Rear feet adjustable at front.

Door weight up to 10 kg.

Door panel dimension dependent on plinth height of kitchen furniture.

Connection

Total connected load 2.0 KW - 2.4 KW. Connecting cable plugable.

Water connection with 3/4 " screw joint.

Connection to hot or cold water possible.

Power consumption standby/network 2 W. Power consumption left-on-mode 0.5 W.

Power consumption off-mode 0.5 W.

Time auto-standby/network 2 min.

Left-on-mode duration 0 min.

Please check the user manual for how to switch off the WiFi module.



Connection dimensions for a 60 cm wide dishwasher $\begin{array}{c} 1.2 \text{ m} \\ \hline \\ (3.7 \text{ m}) 1.5 \text{ m} \\ \hline \\ (3.7 \text{ m}) 1.7 \text{ m} \\ \end{array}$

86.5 cm high dishwasher



