



**BOP250131**

**BA016105:**

1 telescopic shelf rail, for 60cm oven

**BA026115:**

Baking tray, for 60cm oven

**BA036105:**

wire rack, for 60cm oven

**BA046115:**

Glass tray, for 60cm oven

**BA056115:**

Heating elem. 230 V, for 60cm oven

**BA056133:**

Baking stone for 60 cm oven

**BA226105:**

Grill tray, for 60cm oven

**BS020002:**

Set of 2 pizza paddles

**GN340230:**

Gastronorm roaster GN 2/3

#### Built-in oven 200 series

60 x 60 cm, door hinge: right, Gaggenau Silver

**BOP250131**

Flush installation

Pyrolytic system

13 heating methods, with core temperature probe and baking stone function

TFT touch display

Electronic temperature control from 30 °C to 300 °C

Net volume 76 litres

#### Heating methods

Hot air. Eco hot air. Top + bottom heat. Top heat. Bottom heat. Hot air + bottom heat. Full surface grill + circulated air. Full surface grill. Compact grill. Baking stone function. Roaster function. Dough proofing. Defrosting.

#### Handling

Rotary knob and TFT touch display operation.

Clear text display.

Option to save individual recipes (incl. core temperature probe).

Information key with use indicators.

Side-opening door opens up to 110° angle.

#### Features

Core temperature probe with automatic shut-off.

Baking stone socket.

Actual temperature display.

Rapid heating.

Timer functions: cooking time, cooking time end, timer, stopwatch, long-term timer.

60 W halogen light on the top.

Enamelled side shelf supports with 4 tray levels, pyrolysis-safe.

#### Safety

Thermally insulated door with quintuple glazing.

Child lock.

Safety shut-off.

Cooled housing with temperature protection.

#### Cleaning

Pyrolytic system.

Gaggenau enamel.

Heated catalyser to clean the oven air.

#### Planning notes

Door hinge not reversible.

The door panel surface of the appliance extends 21 mm from the furniture cavity.

The outer edge of the door handle extends 72 mm from the furniture cavity.

Necessary lateral gap between appliance door and furniture panel of min. 5 mm.

Consider the overhang, incl. the door handle, when planning to open drawers next to the appliance.

When planning a corner solution, pay attention to the 110° door opening angle.

For installation underneath cooktops: Distance between the underside of the cooktop and the top edge of the oven cavity: min. 15 mm. The planning notes for the cooktops (particularly regarding ventilation, gas/electric connection) must be taken into account.

To achieve the 550 mm installation depth, the connection cable needs to follow the slanted edge on the corner of the housing.

The mains socket needs to be planned outside of the built-in niche.

#### Connection

2.5 energy stars, 5.0 WELS water stars

Total connected load 3.7 KW.

Plan a connection cable.

